



EN Instruction manual
AR الاستخدام



Electric tower heater (Ceramic)
منفأة عمودية كهربية (سيراميك)
01.345036.09.001

PARTS DESCRIPTION /



[WEEE Logo]




Made in China
صنع في الصين

© Princess 2018

EN Instruction manual

SAFETY

- By ignoring the safety instructions the manufacturer can not be hold responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.

-  **WARNING:** In order to avoid overheating, do not cover the heater.
- CAUTION:** Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- Do not use the appliance with a programmer, timer, separate remote-control system or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
- Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
- Joists, beams and rafters shall not be cut or notched to install the appliance.
- Please do not install the appliance close to curtains and other combustible materials. This could cause a fire.
- Regulations concerning the discharge of air have to be fulfilled.
- The appliance shall, under no circumstances, be covered with insulating material or similar material.
- The heater must not be located immediately below a socket-outlet.
- Do not use this heater if it has been dropped.
- Do not use if there are visible signs of damage to the heater.
- Use this heater on a horizontal and stable surface, or fix it to the wall, as applicable.
- WARNING:** Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.
- WARNING:** To reduce the risk of fire, keep textiles, curtain, or any other flammable material a minimum distance of 1m from the air outlet.
- The heater needs to be installed so that the switches and other controls cannot be touched by a person in the bath or shower.
- WARNING:** The heater must not be used if the ceramic panels are damaged.

PARTS DESCRIPTION

- Oscillation knob
- Ventilation knob
- On/off switch
- Power switches

BEFORE THE FIRST USE

- Place the device on a flat stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
- When the device is turned on for the first time, a slight odour will occur. This is normal, ensure adequate ventilation. This fragrance is only temporary and will disappear soon.

CLEANING AND MAINTENANCE

- Unplug the appliance and allow it to cool down. Use a soft, slightly damp cloth to wipe appliance surfaces. Do not allow water or any other liquid to get into the unit.

- Clean the air suction opening from time to time with a fine brush.

WARRANTY

- This product is warrantied for 2 Years, for detailed terms, please refer to the Warranty Card.
- Following parts are not covered by warranty:
 - Knobs.
 - Any broken body parts.

Approximate life of this appliance under normal conditions is 3 Years.

For service and repairs, please call the following numbers:

United Electronics Co.
Saudi Arabia (Toll-free) 800 124 0900

ENVIRONMENT



This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

Support

You can find all available information and spare parts at www.princesshome.eu!

AR دليل الإرشادات

السلامة

- عند إهمال تعليمات السلامة لا تتحمل الشركة طَـمَـنَـة أيّة مسؤولية عن وقوع تـلـفـيـات.
- في حالة تلف سلك الإمداد بالطاقة، يجب استبداله بواسطة الشركة المصنعة أو وكيل الصيانة أو أي في مؤهل لتجنب التعرض إلى المخاطر.
- لا تحرك الجهاز مطلقاً عن طريق سحب السلك، وتأكد من أن السلك لن يصبح متشابك.
- يجب وضع الجهاز على سطح ثابت ومستو.
- يجب ألا يغفل المستخدم عن الجهاز أثناء توصيله بالكهرباء.
- تم تصميم هذا الجهاز للاستخدام المنزلي فقط ولأغراض التي هي من أجلها.
- ينبغي عدم استخدام هذا الجهاز بواسطة أطفال أصغر من 8 سنوات. يمكن استخدام هذا الجهاز بواسطة الأطفال من سن 8 سنوات وما فوق والأشخاص ذوي القدرات الجسدية أو الحسية أو العقلية المحدودة أو الذين يفتقرون إلى الخبرة والمعرفة إذا تم الإشراف عليهم أو إرشادهم بشأن كيفية استخدام الجهاز بطريقة آمنة وفهمهم للمخاطر المحتملة. يجب على الأطفال عدم اللعب بهذا الجهاز. احرص على بقاء الجهاز والسلك بعيدين عن متناول الأطفال أقل من 8 سنوات. يجب على الأطفال عدم القيام بعملية التنظيف وصيانة المستخدم إلا إذا كانوا أكبر من 8 سنوات وفي وجود من يشرف عليهم.
- لحماية نفسك من التعرض إلى صدمة كهربائية، لا تلمس السلك أو المقابس أو الجهاز في الماء أو في أية وسائل أخرى.
- تحذير: لتجنب فرط التسخين، لا تغطي المدفأة.
- تنبيه: قد تصبح بعض الأجزاء الخاصة بهذا المنتج ساخنة للغاية وقد تسبب حروق. يجب الانتباه جيداً عند وجود أطفال أو ذوي احتياجات خاصة.
- لا تستخدم الجهاز مطلقاً مع مبرمج أو مؤقت أو نظام منفصل للتحكم عن بعد أو أي جهاز آخر يقوم بتشغيل المدفأة أوتوماتيكياً؛ نظراً لوجود احتمالية التعرض لخطر نشوب حريق في حالة تغطية المدفأة أو وضعها بشكل غير صحيح.
- لا تستخدم المدفأة في المحيط المباشر للحمام أو منطقة الاستحمام أو حمام السباحة.
- يجب ألا يتم إزالة أو فتح الدعامات والحوامل والعازضات تثبيت الجهاز.
- برجاء عدم تثبيت الجهاز بالقرب من الستائر أو من مواد أخرى قابلة للاحتراق. قد يتسبب هذا في نشوب حريق.
- يجب اتباع القوانين المتعلقة بتفريغ الهواء.
- يجب ألا يتم تغطية الجهاز تحت أي ظرف بمادة عازلة أو مادة مشابهة.
- يجب ألا توضع المدفأة مباشرة تحت مقبس مخرج الطاقة.
- تحتاج المدفأة إلى تركيبها بحيث لا يمكن لأي شخص في الحمام أو أثناء الاستحمام لمس المفاتيح أو وحدات التحكم.
- تحذير: يجب ألا تستخدم المدفأة إذا كانت ألواح السيراميك تالفة.
- لا تستخدم هذا السخان إذا تم إسقاطه
- لا تستخدم إذا كانت هناك علامات و اضحة للضرر على المدفأة
- استخدم هذا السخان على سطح أفقي ومستقر
- ، أو قم بوضعه على الحائط ، حسب الاقتضاء.
- تحذير: لا تستخدم هذا السخان في الغرف الصغيرة
- عندما يشغلها أشخاص غير قادرين على مغادرة الغرفة بمفردهم ، ما لم يتم توفير الإشراف المستمر.
- تحذير: للحد من خطر نشوب حريق ، يرجى الحفاظ على المنسوجات والستائر ، أو أي مادة قابلة للاشتعال الأخرى على بعد أقل من متر واحد من منفذ الهواء.

وصف الأجزاء

- مفتاح التحكم في الدوران
- مفتاح التحكم في التهوية
- مفتاح التشغيل/إيقاف التشغيل
- مفاتيح الطاقة

قبل الاستخدام الأول

- ضع الجهاز على سطح ثابت ومستو وتأكد من وجود حد أدنى من المساحة الحرة حول الجهاز قدرها 10 سم. هذا الجهاز غير مناسب للتركيب في خزانة أو لاستخدامه الخارجي.
- عند تشغيل الجهاز للمرة الأولى، ستشعر رائحة خفيفة. هذا أمر طبيعي، تأكد من وجود تهوية كافية. هذه الرائحة ما هي إلا رائحة مؤقتة وستختفي مع مرور الوقت.

التنظيف والصيانة

- افصل الجهاز عن مصدر التيار واتركه ليبرد قليلاً. استخدم قطعة قماش ناعمة ومبللة قليلاً لمسح أسطح الجهاز. لا تسمح بوصول الماء أو أية وسائل أخرى داخل الجهاز.
- نظف فتحة شقوق الهواء من وقت لآخر بعرضاة ناعمة.

ضمان

- هذا الجهاز مضمون لمدة عامين ، لمعرفة أحكام الضمان يرجى قراءة كرت ضمان المنتج.
- المكونات أدناه غير مسؤولة بالضمان:

— المقابض.

أجزاء السدود القابلة للتحريك.

العمر الافتراضي للجهاز يعتمد على ظروف التشغيل العادية . العمر الافتراضي 3 سنوات تقريبا.

يرجى الاتصال على أرقام خدمة الصيانة والتسليم الآتية:

الشركة المتحدة للإلكترونيات

المملكة العربية السعودية (الرياض الجاهلي) 800 124 0900

البيئية



وسبب العرض الثابت والعقيق، يجب ألا يتم وضع هذا الجهاز في سلة القمامات المنزلية في نهاية عمره الافتراضي، ولكن يجب تقديمه إلى نقطة المركزية لإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. إن كلاً من الرمز الموجود على الجهاز، ودليل التعليمات والتغليف يذكرك من هذه المسألة الهامة. يمكن إعادة تدوير المواد المستخدمة في هذا الجهاز. من خلال إعادة تدوير الأجهزة المنزلية، فإنك تقدم إسهام هام للحفاظ على البيئة التي نعيش فيها. استفسر من السلطات المحلية عن نقطة التجميع ذي.