

EN Instruction manual
AR وصف الأجزاء

Made in China
صنع في الصين



CONTACT GRILL
شواية كونتكت
58.117206.04.001


وصف الأجزاء / PARTS DESCRIPTION



EN Instruction manual

SAFETY

- By ignoring the safety instructions the manufacturer can not be hold responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- Keep the appliance and its cord out of reach of children less than 8 years.
- The temperature of accessible surfaces may be high when the appliance is operating.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.

-  Surface are liable to get hot during use.

PARTS DESCRIPTION

- Thermostat
- Indication light green
- Indication light red
- Grill plates
- Fat collecting tray
- Lock clip

BEFORE THE FIRST USE

- Take the appliance and accessories out the box. Remove the stickers, protective foil or plastic from the device.
- Place the device on a flat stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
- We advise to place a heat resistant coating between your table and the appliance (this way you don't get burns on your table or table cloth).
- When the device is turned on for the first time, a slight odour will occur. This is normal, ensure adequate ventilation. This fragrance is only temporary and will disappear soon.

USE

- To switch on the appliance, insert the mains plug into the wall socket.
- Place a collecting tray below the grease outlet. During the grilling the excess fat from the grill plates runs to the grease outlet. Set the thermostat to the desired temperature.
- Plug in the socket, the red and green indication light will light up. Leave the device closed without any content to preheat. When the green indication light will go off you will be able to start grilling.
- Now place the prepared ingredients on the bottom grill plate and close the grill by pressing the handle downwards. The upper plate tilts in order to provide even pressure. Normal preparation time is 5-8 minutes; the exact time depends on the dish, the set temperature and your personal taste. Because the device is closed the baking process is faster.

CLEANING AND MAINTENANCE

- Remove the plug from the wall outlet and allow the device to cool both halves open.
- Clean the baking plates with a damp cloth or soft brush.
- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.
- Never immerse the electrical device in water or any other liquid. The device is not dishwasher proof.

GUARANTEE

- This product is guaranteed for 24 months granted. Your warranty is valid if the product is used in accordance to the instructions and for the purpose for which it was created. In addition, the original purchase (invoice, sales slip or receipt) is to be submitted with the date of purchase, the name of the retailer and the item number of the product.

ENVIRONMENT



This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

AR دليل الإرشادات

السلامة

- عند إهمال تعليمات السلامة لا تتحمل الشركة المصنّعة أية مسؤولية عن وقوع تلفيات.

- في حالة تلف سلك الإمداد بالطاقة، يجب استبداله بواسطة الشركة المصنعة أو وكيل الصيانة أو أي فني مؤهل لتجنب التعرض إلى المخاطر.
- لا تحرك الجهاز مطلقاً عن طريق سحب السلك، وتأكد من أن السلك لن يصبح متشابكاً.
- يجب وضع الجهاز على سطح ثابت ومستو.
- يجب ألا يغفل المستخدم عن الجهاز أثناء توصيله بالكهرباء
- تم تصميم هذا الجهاز للاستخدام المنزلي فقط وللأغراض التي صُنع من أجلها.
- ينبغي عدم استخدام هذا الجهاز بواسطة أطفال أصغر من 8 سنوات. يمكن استخدام هذا الجهاز بواسطة الأطفال من سن 8 سنوات وما فوق والأشخاص ذوي القدرات الجسدية أو الحسية أو العقلية المحدودة أو الذين يفتقرون إلى الخبرة والمعرفة إذا تم الإشراف عليهم أو إرشادهم بشأن كيفية استخدام الجهاز بطريقة آمنة وفهمهم للمخاطر المحتملة. يجب على الأطفال عدم اللعب بهذا الجهاز. احرص على بقاء الجهاز والسلك بعيدين عن متناول الأطفال أقل من 8 سنوات. يجب على الأطفال عدم القيام بعملية التنظيف وصيانة المستخدم إلا إذا كانوا أكبر من 8 سنوات وفي وجود من يشرف عليهم.
- لحماية نفسك من التعرض إلى صدمة كهربائية، لا تعمس السلك أو القابس أو الجهاز في الماء أو في أية سوائل أخرى.
- احرص على بقاء الجهاز والسلك بعيدين عن متناول الأطفال أقل من 8 سنوات.
- قد تكون درجة حرارة الأسطح الظاهرة مرتفعة عند تشغيل الجهاز.
- هذا الجهاز غير مخصص للتشغيل من خلال مؤقت خارجي أو نظام تحكم عن بعد منفصل.



- قد يسخن السطح أثناء الاستخدام.

وصف الأجزاء

- الترموستات
- مؤشر باللون الأخضر
- مؤشر باللون الأحمر
- ألواح الشواء
- صينية لجمع الدهون
- مثبت القفل

قبل الاستخدام الأول

- قم بإخراج الجهاز وللملحقات خارج العلبة. قم بإزالة الملصقات أو البلاستيك أو ورق التغليف من الجهاز.
- ضع الجهاز على سطح ثابت ومستو وتأكد من وجود حد أدنى من المساحة الحرة حول الجهاز. قدرها 10 سم. هذا الجهاز غير مناسب للتثبيت في خزانة أو للاستخدام خارجي.
- نضع بوضع طبقة مقاومة للحرارة بين الطاوي والجهاز (وبذلك لا يحدث حروق للطاول أو غطائها).
- عند تشغيل الجهاز للمرة الأولى، ستصدر رائحة خفيفة. هذا أمر طبيعي. تأكد من وجود توية كافية. هذه الرائحة ما هي إلا رائحة مؤقتة وستختفي سريعاً.

الاستخدام

- لتشغيل الجهاز، أدخل قابس التيار الكهربائي في مقبس الحائط.
- ضع صينية التجميع أسفل مخرج الدهون. أثناء الشواء، سوف تنصرف الدهون الزائدة عن ألواح الشواء إلى مخرج الدهون.
- اضبط الترموستات إلى درجة الحرارة المرغوب بها.
- وصل القابس في المقبس، حينها سوف يضيئ المؤشر الأحمر والأخضر. اترك الجهاز مغلق دون أي محتوى لتسخينه مسبقاً.
- عندما ينطفئ المؤشر الأخضر، يمكنك حينها بدء الشواء.
- ضع الآن المكونات المضطرة أسفل ألواح الشواء ثم أغلق الشواية من خلال الضغط على القفص إلى الأسفل. يحل اللوح العلوي لكي يوفر ضغط متساوي. بعد وقت الإعداد العادي هو 5-8 دقائق، يجند الوقت المعطى على الطبق ودرجة الحرارة التي تم ضبطها وذلك الشخصي. ونظراً لأن الجهاز مغلق، ستصبح عملية الخبز أسرع.

التنظيف والصيانة

- أزل القابس من مخرج الطاقة الموجود بالحائط ثم اترك الجهاز ليبرد تاركا نصفه مفتوحين.
- قم بتنظيف ألواح الخبز باستخدام قطعة قماش رطبة أو بفرشاة ناعمة.
- تلفظ الجهاز بشفقة قصائر رطبة. لا تستخدم مطلقاً مواد تنظيف قوية أو كاشطة، أو اللوف الخشن أو الألياف السلكية الذي قد يتسبب في تلف الجهاز رطبة.
- احرص ألا تعمس الجهاز الكهربائي أبداً في ماء أو أي سائل آخر. لا يمكن تنظيف الجهاز في غسالة الأطباق.

الضمان

- يتمل هذا المنتج ضمان لمدة 24 شهر. يعتبر هذا الضمان سارياً طالما تم استخدام المنتج حسب التعليمات وللأغراض التي صنع من أجلها الجهاز. إضافة إلى ذلك، يجب إرسال إثبات الشراء الأصلي (فاتورة أو ورقة بيع أو إيصال) مع تاريخ الشراء واسم بائع التجزئة ورقم المنتج.

البيئة



وبسبب العرض الثالث والضيقي، يجب ألا يتم وضع هذا الجهاز في سلة النفايات المنزلية في نهاية عمره الافتراضي، ولكن يجب تقديمه إلى نقطة المركزية لإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. إن كلاً من الزمزم الموجود على الجهاز، ودليل التعليمات والتعليق يذكركم من هذه السلسلة. أقمعة. يمكن إعادة تدوير المواد المستخدمة في هذا الجهاز. من خلال إعادة تدوير الأجهزة المنزلية، فإنك تقدم إسهام هام للحفاظ على البيئة التي نعيش فيها. استفسر من السلطات المحلية عن نقطة التجميع.