



EN Instruction manual

AR الاستخدام



Waffle Iron DeLuxe Duo
01.132394.09.001

PARTS DESCRIPTION / وصف الأجزاء



EN Instruction manual

SAFETY

- By ignoring the safety instructions the manufacturer can not be hold responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children from 0 year to 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- Keep the appliance and its cord out of reach of children less than 8 years.
- The temperature of accessible surfaces may be high when the appliance is operating.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.

PARTS DESCRIPTION

- Thermostat slide
- Power indicator
- Temperature indicator
- Baking plates

BEFORE THE FIRST USE

- Take the appliance and accessories out the box. Remove the stickers, protective foil or plastic from the device.
- Place the device on a flat stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
- Put the power cable into the socket. (Note: Make sure the voltage which is indicated on the device matches the local voltage before connecting the device. Voltage 220V-240V 50/60Hz)
- Set the thermostat slide to the highest setting and allow the device to preheat until the ready light illuminate green.
- When the device is turned on for the first time, a slight odor will occur. This is normal, ensure adequate ventilation. This fragrance is only temporary and will disappear soon.
- Place the device in a well ventilated space.

USE

- Insert the plug into the wall socket. The orange light goes on.
- After a short warm-up period of approx. 5 minutes with the plates closed (the green light goes on) the waffle maker is ready for use.
- Open the waffle maker and grease both baking plates with some oil or fat.
- Place the prepared waffle dough on the lower baking tray.
- Set the thermostat slide to the desired setting.
- The baking time in every setting is 3 to 5 minutes, depending on the kind of dough and your own wishes.
- Do not use sharp objects to remove your waffle, in order to prevent damage to the non stick coating.

Buzzer

- When you plug in the device the buzzer will sound three times.
- Set the control thermostat slide to the desired setting, when the temperature of the desired setting is reached the buzzer will sound three times.
- When the temperature will come below the temperature of the desired setting the buzzer will sound three times to indicate that the device will heat up again.
- When the device reached the temperature of the desired setting again the buzzer will sound three times.

CLEANING AND MAINTENANCE

- Remove the plug from the wall outlet and allow the device to cool both halves open.
- Clean the baking plates with a damp cloth or soft brush.
- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.
- Never immerse the electrical device in water or any other liquid. The device is not dishwasher proof.

WARRANTY

- his product is warrantied for 2 Years, for detailed terms, please refer to the Warranty Card.
- Following parts are not covered by warranty:
 - Knobs.
 - Any broken body parts.

Approximate life of this appliance under normal conditions is 3 Years.

For service and repairs, please call the following numbers:

United Electronics Co.
Saudi Arabia (Toll-free) 800 124 0900

ENVIRONMENT

- This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By

recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

AR

- عند إهمال تعليمات السلامة لا تتحمل الشركة المُصنعة أية مسئولية عن وقوع تلفيات.
- في حالة تلف سلك الإمداد بالطاقة، يجب استبداله بواسطة الشركة المصنعة أو وكيل الصيانة أو أي فني مؤهل لتجنب التعرض إلى المخاطر.
- لا تحرك الجهاز مطلقاً عن طريق سحب السلك، وتأكد من أن السلك لن يصبح متشابكاً.
- يجب وضع الجهاز على سطح ثابت ومستو.
- يجب ألا يغفل المستخدم عن الجهاز أثناء توصيله بالكهرباء.
- تم تصميم هذا الجهاز للاستخدام المنزلي فقط ولأغراض التي صُنع من أجلها.
- ينبغي عدم استخدام هذا الجهاز بواسطة أطفال حتى عمر 8 سنوات. يمكن استخدام هذا الجهاز بواسطة الأطفال من سن 8 سنوات وما فوق والأشخاص ذوي القدرات الجسدية أو الحسية أو العقلية المحدودة أو الذين يفتقرون إلى الخبرة والمعرفة إذا تم الإشراف عليهم أو إرشادهم بشأن كيفية استخدام الجهاز بطريقة آمنة وفهمهم للمخاطر المحتملة. يجب على الأطفال عدم اللعب بهذا الجهاز.
- احرص على بقاء الجهاز والسلك بعيدين عن متناول الأطفال أقل من 8 سنوات.
- يجب على الأطفال عدم القيام بعملية التنظيف وصيانة المستخدم إلا إذا كانوا أكبر من 8 سنوات وفي وجود من يشرف عليهم.
- لحماية نفسك من التعرض إلى صدمة كهربائية، لا تغمس السلك أو القابض أو الجهاز في الماء أو في أية سوائل أخرى.
- احرص على بقاء الجهاز والسلك بعيدين عن متناول الأطفال أقل من 8 سنوات.
- قد تكون درجة حرارة الأسطح الظاهرة مرتفعة عند تشغيل الجهاز.
- هذا الجهاز غير مخصص للتشغيل من خلال مؤقت خارجي أو نظام تحكم عن بعد منفصل.

وصف الأجزاء

- مؤلاق الترموستات
- مؤشر الطاقة
- مؤشر درجة الحرارة
- ألواح الخبز

قبل الاستخدام الأول

- قم بإخراج الجهاز والملحقات خارج العلبة. قم بإزالة الملصقات، أو ورق الأوكسنيوم اللاصق عن الجهاز.
- ضع الجهاز على سطح ثابت ومستو وتأكد من وجود حد أدنى من المساحة الحرة حول الجهاز. قدرها 10 سم. هذا الجهاز غير مناسب للتركيب في خزانة أو للاستخدام الخارجي.
- ضع كابل الطاقة في المقبس. (ملاحظة: تأكد أن الجهد الكهربائي المشار إليه على الجهاز مطابق للحدود المحلي قبل توصيل الجهاز. الجهد الكهربائي 220V-240V فولت. 50/60Hz هرتز)
- حرك مؤلاق الترموستات إلى أعلى درجة حرارة واترك الجهاز ليسخن حتى تنضي لمة الاستعداد باللون الأخضر.
- بعد تشغيل الجهاز للمرة الأولى، ستصدر رائحة خفيفة. هذا أمر طبيعي، تأكد من وجود تهوية كافية. هذه الرائحة ما هي إلا رائحة مؤقتة وستختفي سريعاً.
- ضع الجهاز في مكان معرض لتهوية جيدة

الاستخدام

- أدخل القابس في مقبس الحائط. ستضيء اللبنة باللون البرتقالي.
- بعد مرور فترة إحماء قصيرة تبلغ 5 دقائق أثناء غلق الألواح (تضوء اللبنة باللون الأخضر) تكون صاعدة الوافل جاهزة للاستخدام.
- فتح صاعدة الوافل وإدخال ألواح الخبز بعض من الزيت أو الدough.
- ضع صينية الوافل المحمّرة على صينية الخبز السفلى.
- حرك مؤلاق الترموستات إلى درجة الحرارة المرغوب بها.
- رغم الخبز في كل إعداد يستغرق من 3 إلى 5 دقائق، وفقاً لنوع العجينة ورضيتك.
- لا تستخدم أدوات حادة لإزالة الوافل بلع إخراج التلف بالطبقة غير اللاصقة.

صيانة

- عند توصيل الجهاز بالطاقة ستصدر صمارة ثلاث مرات.
- حرك مؤلاق التحكم في الترموستات إلى درجة الحرارة المطلوبة، عند وصول الجهاز إلى درجة الحرارة المحددة ستصدر صمارة ثلاث مرات.
- عند انخفاض درجة الحرارة عن الإعداد المحدد ستصدر صمارة ثلاث مرات للإشارة إلى أن الجهاز سيبدأ في الإحماء مرة ثانية.
- عند وصول الجهاز إلى درجة الحرارة المطلوبة مرة أخرى ستصدر صمارة ثلاث مرات.

التنظيف والصيانة

- إزل القابس من مخرج الطاقة الموجود بالحائط ثم اترك الجهاز ليبرد تاركاً نصفه مفتوحين.
- قم بتنظيف ألواح الخبز باستخدام قطعة قماش رطبة أو بفرشاة ناعمة.
- نظف الجهاز بقطعة قماش رطبة. لا تستخدم مطلقاً مواد تنظيف قوية أو كاشطة، أو اللوف الخشن أو الألياف السلكية الذي قد يتسبب في تلف الجهاز.
- احرص ألا تغمس الجهاز الكهربائي أبداً في الماء أو أي سائل آخر. لا يمكن تنظيف الجهاز في غسالة الأطباق.

الضمان

- يتم توفير ضمان لمدة عامان هذا المنتج، لقراءة شروط الضمان التفصيلية يرجى الرجوع إلى بطاقة الضمان.
- لا يغطي الضمان الأجزاء التالية:

— المقبض

— أي أجزاء مكسورة.

عمر حياة هذا الجهاز 3 سنوات في ظل ظروف التشغيل العادية.

للمبيعات والخدمة يرجى الاتصال بالرقم التالي:

United Electronics Co

المسجلة (رقم مجاني) 800 124 800



وسبب العرض الثابت والضيق، يجب ألا يتم وضع هذا الجهاز في سلة القمامات المنزلية في نهاية عمره الافتراضي، ولكن يجب تقديمه إلى النقطة المركزية لإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. إن كلاً من الرمز الموجود على الجهاز، ودليل التعليمات والتغليف يحملان من هذه السلسلة الهامة. يمكن إعادة تدوير المواد المستخدمة في هذا الجهاز. من خلال إعادة تدوير الأجهزة المنزلية، فإنك تقدم إسهام هام للحفاظ على البيئة التي نعيش فيها. استفسر من السلطات المحلية عن نقطة التجميع.