



EN Instruction manual

الاستخدام




Citrus Juicer Classic  
عصرارة الحمضيات كلاسيك بلاك  
01.201004.04.001



Made in China  
صنع في الصين

PARTS DESCRIPTION / وصف الأجزاء



[WEEE Logo]



## EN Instruction manual

### SAFETY

- By ignoring the safety instructions the manufacturer can not be hold responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- Do not allow children to use the device without supervision.
- Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
- Always disconnect the device from the supply if it is left unattended and before assembling, disassembling or cleaning.
- It is absolutely necessary to keep this appliance clean at all times, because it comes into direct contact with food.
- This appliance is intended to be used in household and similar applications such as:
  - Staff kitchen areas in shops, offices and other working environments.
  - By clients in hotels, motels and other residential type environments.
  - Bed and breakfast type environments.
  - Farm houses.

### PARTS DESCRIPTION

- Cover
- Press cone
- Filter
- Jug
- Axis

### BEFORE THE FIRST USE

- Take the appliance and accessories out the box. Remove the stickers, protective foil or plastic from the device.
- Before using your appliance for the first time, wipe off all removable parts with a damp cloth. Never use abrasive products.
- Connect the power cable to the socket. (Note: Make sure the indicated voltage on the device matches the local voltage before connecting the device. Voltage 220V-240V 50-60Hz.

### USE

- Choose an appropriate cone, depending on the size of the fruit. The small cone for straining small fruits such as kiwi, peach or mandrel. The large cone is for straining big fruits such as oranges and grapefruit. The large cone has to be placed on top of the small cone. To use the large cone, the small cone has to be placed on the device too.
- As soon as the half citrus fruit is pressed onto the juice cone, the motor will be activated.
- The motor automatically changes directions when it is switched on and off. The change of direction increases the juice collected.
- Do not exert too much pressure on the juice cone. If the sound of the motor increases significantly or the motor itself slows down dramatically, this means too much pressure has been exerted.
- The filter can be adjusted, it can be turned to only let juice or also pulp pass through.
- Do not run the device for more than 15 seconds without interruption.

### CLEANING AND MAINTENANCE

- Unplug the appliance. Use a soft, slightly damp cloth to wipe appliance surfaces. Do not allow water or any other liquid to get into the unit.
- Never immerse the device in water or any other liquid. The device is not dishwasher proof.
- Clean the accessories with warm soapy water to avoid bacterial growth. The accessories are also dishwasher proof.
- Components that have come into contact with food can be cleaned in soapy water.

### GUARANTEE

- This product is guaranteed for 24 months granted. Your warranty is valid if the product is used in accordance to the instructions and for the purpose for which it was created. In addition, the original purchase (invoice, sales slip or receipt) is to be submitted with the date of purchase, the name of the retailer and the item number of the product.

### ENVIRONMENT



This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be

recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

## AR دليل الإرشادات

### السلامة

- عند إهمال تعليمات السلامة لا تتحمل الشركة المصنعة أية مسئولية عن وقوع تلفيات.
- في حالة تلف سلك الإمداد بالطاقة، يجب استبداله بواسطة الشركة المصنعة أو وكيل الصيانة أو أي فني مؤهل لتجنب التعرض إلى المخاطر.
- لا تحرك الجهاز مطلقًا عن طريق سحب السلك، وتأكد من أن السلك لن يصبح متشابكًا.
- يجب وضع الجهاز على سطح ثابت ومستو.
- يجب ألا يغفل المستخدم عن الجهاز أثناء توصيله بالكهرباء
- تم تصميم هذا الجهاز للاستخدام المنزلي فقط وللأغراض التي صُنع من أجلها.
- ينبغي عدم استخدام هذا الجهاز بواسطة أطفال أصغر من 8 سنوات. يمكن استخدام هذا الجهاز بواسطة الأطفال من سن 8 سنوات وما فوق والأشخاص ذوي القدرات الجسدية أو الحسية أو العقلية المحدودة أو الذين يفتقرون إلى الخبرة والمعرفة إذا تم الإشراف عليهم أو إرشادهم بشأن كيفية استخدام الجهاز بطريقة آمنة وفهمهم للمخاطر المحتملة. يجب على الأطفال عدم اللعب بهذا الجهاز. احرص على بقاء الجهاز والسلك بعيدين عن متناول الأطفال أقل من 8 سنوات. يجب على الأطفال عدم القيام بعملية التنظيف وصيانة المستخدم إلا إذا كانوا أكبر من 8 سنوات وفي وجود من يشرف عليهم.
- لحماية نفسك من التعرض إلى صدمة كهربائية، لا تمس السلك أو القابس أو الجهاز في الماء أو في أية سائل أخرى.
- لا تسمح للأطفال باستخدام الجهاز بدون الإشراف عليهم.
- قم بإيقاف الجهاز وفصله عن مصدر الطاقة قبل تغيير الملحقات أو الاقتراب من الأجزاء المتحركة المستخدمة.
- قم دائمًا بفصل الجهاز عن مصدر الطاقة في حالة تركه بدون مراقبة أو قبل التركيب أو الفك أو التنظيف.
- من الضروري للغاية الحفاظ على هذا الجهاز نظيف طوال الوقت، لأنه يلامس الطعام بشكل مباشر
- هذا الجهاز مخصص للاستخدام المنزلي وللإستخدام في الأماكن المشابهة مثل:
  - أماكن مطابخ الموظفين في المناجر والمكاتب وأماكن العمل الأخرى.
  - أو من قبل نزلاء الفنادق والاستراحات والأماكن السكنية الأخرى.
  - والأماكن التي تقدم ميثا ووجبة إفطار.
  - والمزارل الريفية.

### وصف الأجزاء

- الغطاء
- أداة العصر مخروطية الشكل
- الصفارة
- الوعاء
- محور الدوران

### قبل الاستخدام الأول

- قم بإخراج الجهاز والملحقات خارج العلية. قم بإزالة الملصقات، أو ورق الألويموم اللصقي عن الجهاز.
- قبل الاستخدام الأول، قم بمسح جميع الأجزاء القابلة للإزالة بقطعة قماش رطبة. لا تستخدم مطلقًا آلة متحات كاشطة.
- ضع كبل الطاقة في المنقبس، (ملاحظة: تأكد من أن المهبط الذي يشار إليه على الجهاز يتطابق مع المهبط المرفق قبل توصيل الجهاز. المهبط 220 فولت -240 فولت 50-60 هرتز)

### الاستخدام

- اختر الأداة المخروطية المناسبة وفقًا لحجم الفاكهة. فالأداة المخروطية صغيرة الحجم تناسب عصر قمار الفاكهة صغيرة الحجم مثل قمار الكيوي أو الخوخ أو الليمون. أما الأداة المخروطية كبيرة الحجم فتناسب عصر قمار الفاكهة كبيرة الحجم مثل البرتقال والخرطب فروت. ويجب تركيب الأداة المخروطية كبيرة الحجم فوق الأداة المخروطية صغيرة الحجم. بعد استعمال الأداة المخروطية كبيرة الحجم، يجب تركيب الأداة المخروطية صغيرة الحجم أيضًا للجهاز.
- بحرص الضغط على نصف كرة الفاكهة الحشوية في هيكل العصور، سيتم تشغيل الموتور.
- يتمز الموتور أو مانيكتا من الانجذاعات عند تشغيله وإيقافه. يحد تغير الاتجاه من كمية العصور.
- تجنب الضغط المفرط على أداة العصر مخروطية الشكل. وإذا لاحظت ارتفاع صوت المحرك بدرجة كبيرة أو تباطؤ شديد في حركته، فذلك يدل على زيادة الضغط عن القدر اللازم.
- يمكن تعديل وضع الصفارة، فيمكن تدويرها فهد السباح يتناسب العصور منها أو لإتاحة نفاذ لب الفاكهة حالما.
- لا تشغل الجهاز لمدة تزيد عن 15 ثانية بدون توقف.

### التنظيف والصيانة

- افصل الجهاز عن مصدر التيار. استخدم قطعة قماش ناعمة ومبللة قليلًا لمسح أسطح الجهاز. لا تسمح بوصول الماء أو أية سائل أخرى داخل الجهاز.
- احرص ألا تغمس الجهاز أبدًا في الماء أو أي سائل آخر. لا يمكن تنظيف الجهاز في غسالة الأطباق.
- قم بتنظيف الملحقات باستخدام ماء دافئ وصابون لتجنب فو البكتيريا. كما يمكن تنظيف الملحقات في غسالة الأطباق.
- يمكن تنظيف المكونات التي تلامس الغذاء مباشرة بماء وصابون.

### الضمان

- يحمل هذا المنتج ضمان لمدة 24 شهر. يعتبر هذا الضمان ساريًا طالما تم استخدام المنتج حسب التعليمات والأغراض التي صنع من أجلها الجهاز. إضافة إلى ذلك، يجب إرسال إثبات الشراء الأصلي (فاتورة أو ورقة بيع أو إيصال) مع تاريخ الشراء واسم باع التجارة ورقم المنتج.

### البيئة



وبسبب العرض الثابت والضييق، يجب ألا يتم وضع هذا الجهاز في سلة النفايات المنزلية في غابة عمره الإقتصادي، ولكن يجب تقديمه إلى النقطة المركزية لإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. إن كلاً من الرمز الموجود على الجهاز، ودليل التعليمات والتعليق يحدرك من هذه السألة الهامة. يمكن إعادة تدوير المواد المستخدمة في هذا الجهاز. من خلال إعادة تدوير الأجهزة المنزلية، فإنك تقدم إسهام هام للحفاظ على البيئة التي نعيش فيها. استفسر من السلطات المحلية عن نقطة التجميع.

Made in China  
صنع في الصين

© Princess 2019