



EN Instruction manual

AR الاستخدام

Made in China

صنع في الصين



Blender  
الخلاط

01.212073.04.001

PARTS DESCRIPTION / وصف الأجزاء



[WEEE Logo]



## EN Instruction manual

### SAFETY

- By ignoring the safety instructions the manufacturer can not be hold responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- Do not allow children to use the device without supervision.
- Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
- Always disconnect the device from the supply if it is left unattended and before assembling, disassembling or cleaning.
- It is absolutely necessary to keep this appliance clean at all times, because it comes into direct contact with food.
- NOTE: The chopping blades are very sharp, avoid physical contact during emptying and cleaning the device, you can seriously injure.
- This appliance is intended to be used in household and similar applications such as:

- Staff kitchen areas in shops, offices and other working environments.
- By clients in hotels, motels and other residential type environments.
- Bed and breakfast type environments.
- Farm houses.

### PARTS DESCRIPTION

- Lid with feeding shaft
- Can
- Blades
- Grinder cup flat blade (dry grinding)
- Grinder cup cross blade (wet grinding)
- Grinder cup lid
- Speed selector
- Base

### BEFORE THE FIRST USE

- Place the device on a flat stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
- Take the appliance and accessories out of the box. Remove the stickers, protective foil or plastic from the device.
- Before using your appliance for the first time, wipe off all removable parts with a damp cloth. Never use abrasive products.
- Caution! Run the blender no longer than 1 minute continuous, after that always cool the blender for 1 minute.
- The blades of the slicing and chopping disk and the blade chopping are very sharp, avoid physical contact, you can seriously injure.

### Assembly the jar

- Place the jar onto the appliance. Lock the jar by turning it counter clockwise.

### Assembly the grinder cup

- Place the grinder cup lid on the grinder cup and turn it clockwise to lock.
- Place the grinder cup onto the appliance, lock the grinder cup by turning it counter clockwise.

### USE

NOTE: This appliance contains a safety switch, place the jar on the base and turn it counter clockwise until it clicks otherwise the device will not function.

- Cut the fruit and/or vegetables into pieces that fit in the jar. Do not cut into pieces that are too large, since they will need to be small enough to fall to the base of the jar. put the ingredients in the jar and place the jar lid onto the jar.
- Set the speed selector to the desired speed setting, use the pulse function for short and fast chopping for all kind of food.

NOTE: do not operate the blender more than 2 minutes.

NOTE: do not operate the chopper more than 30 seconds.

### CLEANING AND MAINTENANCE

- Always remove the plug from the socket when the device will be cleaned.
- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.
- Never immerse the electrical device in water or any other liquid. The device is not dishwasher proof.
- Components that have come into contact with food can be cleaned in soapy water.

### ENVIRONMENT



This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

## AR دليل الإرشادات

- السلامة
- عند إهمال تعليمات السلامة لا تتحمل الشركة المصنّعة أية مسؤولية عن وقوع تلفيات.
- في حالة تلف سلك الإمداد بالطاقة، يجب استبداله بواسطة الشركة المصنعة أو وكيل الصيانة أو أي في موهل لتحجب التعرض إلى المخاطر.
- لا تحرك الجهاز مطلقًا عن طريق سحب السلك، وتأكد من أن السلك لن يصبح متشابكًا.
- يجب وضع الجهاز على سطح ثابت ومستو.
- يجب ألا يغفل المستخدم عن الجهاز أثناء توصيله بالكهرباء
- تم تصميم هذا الجهاز للاستخدام المنزلي فقط وللأغراض التي صُنِع من أجلها.
- ينبغي عدم استخدام هذا الجهاز بواسطة أطفال أصغر من 8 سنوات. يمكن استخدام هذا الجهاز بواسطة الأطفال من سن 8 سنوات وما فوق والأشخاص ذوي القدرات الجسدية أو الحسية أو العقلية المحدودة أو الذين يفتقرون إلى الخبرة والمعرفة إذا تم الإشراف عليهم أو إرشادهم بشأن كيفية استخدام الجهاز بطريقة آمنة وفهمهم للمخاطر المحتملة. يجب على الأطفال عدم اللعب بهذا الجهاز. احرص على بقاء الجهاز والسلك بعيدين عن متناول الأطفال أقل من 8 سنوات. يجب على الأطفال عدم القيام بعملية التنظيف وصيانة المستخدم إلا إذا كانوا أكبر من 8 سنوات وفي وجود من يشرف عليهم.
- لحماية نفسك من التعرض إلى صدمة كهربائية، لا تغمس السلك أو القابس أو الجهاز في الماء أو في أية سوائل أخرى.
- لا تسمح للأطفال باستخدام الجهاز بدون الإشراف عليهم.
- قم بإيقاف الجهاز وفصله عن مصدر الطاقة قبل تغيير الملحقات أو الاقتراب من الأجزاء المتحركة المستخدمة.
- قم دائمًا بفصل الجهاز عن مصدر الطاقة في حالة تركه بدون مراقبة أو قبل التركيب أو الفك أو التنظيف.
- من الضروري للغاية الحفاظ على هذا الجهاز نظيف طوال الوقت، لأنه يلامس الطعام بشكل مباشر
- ملاحظة: إن شفرات الفرم حادة للغاية، لذلك تجنب ملامستها الجسم أثناء تفريغ الجهاز أو تنظيفه، لأن ذلك قد يصيبك بجرح بالغ.
- هذا الجهاز مخصص للاستخدام المنزلي والاستخدام في الأماكن المشابهة مثل:
  - أماكن مطابخ الموظفين في المطاعم والمكاتب وأماكن العمل الأخرى.
  - أو من قبل نزلاء الفنادق والاسرحات والأماكن السكنية الأخرى.
  - والأماكن التي تقدم ميثا ووجبة إفطار.
  - والمزارل الريفية.

### وصف الأجزاء

- غطاء مزود بقناة تغذية
- الوعاء
- الشفرات
- شفرة مستقيمة لوعاء المطحنة (الطحن الجاف)
- شفرة منقطة لوعاء المطحنة (الطحن الرطب)
- غطاء وعاء المطحنة
- محدد السرعة
- القاعدة

### قبل الاستخدام الأول

- ضع الجهاز على سطح ثابت ومستو وتأكد من وجود حد أدنى من المساحة الحالية حول الجهاز قدرها 10 سم. هذا الجهاز غير مناسب للتركيب في خزانة أو للاستخدام الخارجي.
- قم بإخراج الجهاز والملحقات خارج العلية. قم بإزالة الملصقات، أو البلاستيك أو ورق الأوكسيوم الواقى عن الجهاز.
- قبل الاستخدام الأول، قم بمسح جميع الأجزاء القابلة للإزالة بقطعة قماش رطبة. لا تستخدم مطلقاً آلة منتجات كاشطة.
- تنبيه! قم بتشغيل الخلاط لمدة لا تزيد عن دقيقة متواصلة، وبعد ذلك ترك الخلاط لهذا لمدة دقيقة واحدة.
- تنبيه! شفرات فرس التقطيع وفرس الفرم حادة للغاية، لذلك تجنب ملامستها الجسم لأنه قد يعرضك لإصابات بالغ.

### تجميع الوعاء

- قم بتركيب الوعاء على الجهاز. أغلق الوعاء بتدويره في عكس اتجاه عقارب الساعة.

### تجميع وعاء المطحنة

- قم بتركيب غطاء وعاء المطحنة على وعاء المطحنة ثم أدرك باتجاه عقارب الساعة.
- قم بتركيب وعاء المطحنة على الجهاز. أغلق وعاء وعاء المطحنة من خلال إدارته عكس اتجاه عقارب الساعة.

### الاستخدام

- ملاحظة: تجويز هذا الجهاز على مفتاح السلامة، ضع الوعاء على القاعدة وقم بإدارته عكس اتجاه عقارب الساعة حتى تسمع صوت استقراره في مكانه وإلا لن يعمل الجهاز.
- قم بتقطيع الفواكه و/أو الخضروات إلى قطع بالتم حجمها الوعاء. لا تقم بتقطيع قطع كبيرة للغاية حيث يجب أن تكون القطع صغيرة بما يكفي لتصل إلى قاع الوعاء. ضع المكونات في الوعاء وقم بتركيب الغطاء أعلاه.
- اضبط محدد السرعة على إعداد السرعة المطلوب، استخدم وظيفة التضيئ للزوم السريع لجميع أنواع الطعام.
- ملاحظة: تجنب تشغيل الخلاط لأكثر من دقيقتين.
- ملاحظة: تجنب تشغيل الفرمية لأكثر من 30 ثانية.

### التنظيف والصيانة

- أزل القابس دائماً من مقبس الحائط عند تنظيف الجهاز.
- نظف الجهاز بقطعة قماش رطبة. لا تستخدم مطلقاً مواد تنظيف قوية أو كاشطة، أو اللوف الخشن أو الألياف السلكية الذي قد يتسبب في تلف الجهاز.
- احرص ألا تغمر الجهاز الكهربائي أبداً في الماء أو أي سائل آخر. لا يمكن تنظيف الجهاز في غسالة الأطباق.
- يمكن تنظيف المكونات التي تلامس الغذاء مباشرة بماء وصابون.

### البينة



و بسبب العرض الثالث والقيس، يجب ألا يتم وضع هذا الجهاز في سلة القمامات المنزلية في نهاية عمره الافتراضي، ولكن يجب تقديمه إلى نقطة المركزية لإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. إن كلاً من الرمز الموجود على الجهاز ودليل التعليمات والتعليم يظهران من هذه السلسلة العامة. يمكن إعادة تدوير المواد المستخدمة في هذا الجهاز. من خلال إعادة تدوير الأجهزة المنزلية، فإنك تقدم إسهام هام للحفاظ على البيئة التي نعيش فيها. استفسر من السلطات المحلية عن نقطة التجميع.

Made in China

صنع في الصين

© Princess 2019