



EN Instruction manual

الاستخدام



Jug Kettle

غلاية ماء

Made in China
صنع في الصين

01.236035.04.001

PARTS DESCRIPTION / وصف الأجزاء



[WEEE Logo]



EN Instruction manual

SAFETY

- By ignoring the safety instructions the manufacturer can not be hold responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, offices and other working environments.
 - By clients in hotels, motels and other residential type environments.
 - Bed and breakfast type environments.
 - Farm houses.
- Children shall not play with the appliance.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- If the kettle is overfilled, boiling water may be ejected.
- Do not remove the lid while the water is boiling.
- Please use the kettle only with the stand provided.
- Caution: Insure that the kettle is switched off before removing it from its stand.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- Only use the appliance with the appropriate connector.

PARTS DESCRIPTION

- Cover
- On/Off switch
- Handle
- Power indicator
- Base
- Button to open lid

BEFORE THE FIRST USE

- Take the appliance and accessories out the box. Remove the stickers, protective foil or plastic from the device.
- Place the device on a flat stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
- Before the first use boil a full kettle of water to clean the kettle and discard this water.
- Connect the power cable to the socket. (Note: Make sure the indicated voltage on the device matches the local voltage before connecting the device. Voltage 220V-240V 50-60Hz.

USE

- Always remove the kettle from the base when filling it, this to avoid water dripping into the base.
- Make sure the water level will never exceed the maximum level marker.
- If not enough water is used, the kettle will switch off, with too much water it may boil over. Switch the device on by pressing at the on/off switch. The indicator light will be illuminated. Once the water has boiled, the on/off switch returns automatically to the off position.
- If the appliance is accidentally switched on when empty, the boil-dry protection will automatically switch it off. Adding cool water will cool the boil-dry protection mechanism which enables you to use the kettle as normal.

CLEANING AND MAINTENANCE

- Before cleaning, unplug the appliance and wait for the appliance to cool down.
- Use a soft damp cloth to clean the housing of the device.
- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.
- Never immerse the kettle and base in water or any other liquids.
- The device should be regularly decalcified. Use a descaling product which is suitable for household appliances.
- Rinse the kettle several times with clean water after descaling.

GUARANTEE

- This product is guaranteed for 24 months granted. Your warranty is valid if the product is used in accordance to the instructions and for the purpose for which it was created. In addition, the original purchase (invoice, sales slip or receipt) is to be submitted with the date of purchase, the name of the retailer and the item number of the product.

ENVIRONMENT



This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

Support

You can find all available information and spare parts at www.princesshome.eu!

AR دليل الإرشادات

السلامة

- عند إهمال تعليمات السلامة لا تتحمل الشركة المصنعة أية مسؤولية عن وقوع تلفيات.
- في حالة تلف سلك الإمداد بالطاقة، يجب استبداله بواسطة الشركة المصنعة أو وكيل الصيانة أو أي في مؤهل لتجنب التعرض إلى المخاطر.
- لا تحرك الجهاز مطلقًا عن طريق سحب السلك، وتأكد من أن السلك لن يصبح متشابكًا.
- يجب وضع الجهاز على سطح ثابت ومستو.
- يجب ألا يغفل المستخدم عن الجهاز أثناء توصيله بالكهرباء
- تم تصميم هذا الجهاز للاستخدام المنزلي فقط وللأغراض التي صُنع من أجلها.
- ينبغي عدم استخدام هذا الجهاز بواسطة أطفال أصغر من 8 سنوات. يمكن استخدام هذا الجهاز بواسطة الأطفال من سن 8 سنوات وما فوق والأشخاص ذوي القدرات الجسدية أو الحسية أو العقلية المحدودة أو الذين يفتقرون إلى الخبرة والمعرفة إذا تم الإشراف عليهم أو إرشادهم بشأن كيفية استخدام الجهاز بطريقة آمنة وفهمهم للمخاطر المحتملة. يجب على الأطفال عدم اللعب بهذا الجهاز. احرص على بقاء الجهاز والسلك بعيدين عن متناول الأطفال أقل من 8 سنوات. يجب على الأطفال عدم القيام بعملية التنظيف وصيانة المستخدم إلا إذا كانوا أكبر من 8 سنوات وفي وجود من يشرف عليهم.
- لحماية نفسك من التعرض إلى صدمة كهربائية، لا تغمس السلك أو القابس أو الجهاز في الماء أو في أية سوائل أخرى.
- هذا الجهاز مخصص للاستخدام المنزلي وللاستخدام في الأماكن المشابهة مثل:
 - أماكن مطبخ الموظفين في الفنادق والمكاتب وأماكن العمل الأخرى.
 - أو من قبل نزلاء الفنادق والاستراحات والأماكن السكنية الأخرى.
 - والأماكن التي تقدم مبيتًا ووجبة إفطار.
 - والمزارل الريفية.
- يجب على الأطفال عدم اللعب بهذا الجهاز.
- لا ينبغي استخدام هذا الجهاز من قبل الأطفال. احرص على حفظ الجهاز والسلك الخاص به بعيدًا عن متناول الأطفال
- إذا تم ملء الغلاية حتى تقفيض، قد ينسكب الماء المغلي
- لا تقم بإزالة الغطاء أثناء غليان الماء.
- يرجى استخدام الغلاية فقط مع الحامل المرفق معها.
- تنبيه: تأكد من إيقاف الغلاية عن التشغيل قبل إزالتها من الحامل.
- لحماية نفسك من التعرض إلى صدمة كهربائية، لا تغمس السلك أو القابس أو الجهاز في الماء أو في أية سوائل أخرى.
- لا تستخدم الجهاز إلا مع الموصل المناسب فقط.

وصف الأجزاء

- الغطاء
- زر تشغيل/إيقاف
- المقبض
- مؤشر الطاقة
- القاعدة
- زر لفتح الغطاء

قبل الاستخدام الأول

- قم بإخراج الجهاز والملحقات خارج العلبة. قم بإزالة الملصقات، أو اللاصق أو ورق الأوسيوم الواقى عن الجهاز.
- ضع الجهاز على سطح ثابت ومستو وتأكد من وجود حد أدنى من المساحة الحالية حول الجهاز قدرها 10 سم. هذا الجهاز غير مناسب للتثبيت في خزانة أو للاستخدام الخارجي.
- قبل الاستخدام الأول قم بغلي غلاية مملوءة بالكامل بماء لتطهير الغلاية ثم تخلص من هذا الماء.
- قم بتوصيل كابل الطاقة في المقبس. (ملاحظة: تحقق من أن الجهد الكهربائي المحدد على الجهاز، يتطابق الجهد الكهربائي قبل توصيل الجهاز. الجهد الكهربائي 220 إلى 240 فولت - 50 إلى 60 هرتز.

الاستخدام

- قم دائمًا بإزالة الغلاية من القاعدة عند ملئها، لتجنب تساقط المياه على القاعدة.
- تأكد من أن مستوى المياه لا يتجاوز علامة الحد الأقصى.
- إذا لم يتم استخدام مياه كافية، ستوقف الغلاية عن التشغيل، بينما في حالة وضع الكثير من المياه قد ينسكب من الغلاية. قم بتشغيل الجهاز من خلال الضغط على مفاتيح التشغيل/الإيقاف. ستضيء إضاءة المؤشر. بمجرد أن يغلي الماء، سيعود مفتاح التشغيل/إيقاف التشغيل أوتوماتيكيًا إلى وضع إيقاف التشغيل.
- إذا تم تشغيل الجهاز عن طريق الخطأ وهو فارغ، ستقوم حساسة الحماية من الغليان الجاف أوتوماتيكيًا بإيقاف تشغيل الغلاية. إن إضافة الماء البارد ستعمل على توريد آلية الحماية من الغليان الجاف والتي تستهلك من استخدام الغلاية كالمعتاد.

التنظيف والصيانة

- قبل التنظيف، فصل الجهاز من المقبس وانظر حتى يبرد الجهاز.
- استخدم قطعة قماش رطبة ناعمة لتنظيف مبيت الجهاز.
- نظف الجهاز بقطعة قماش رطبة. لا تستخدم مطلقًا مواد تنظيف قوية أو كاشطة، أو اللوف الخشن أو الألياف السلكية الذي قد يتسبب في تلف الجهاز.
- احرص ألا تغمس الغلاية والقاعدة أبدًا في الماء أو أي سائل آخر.
- يجب إزالة الكالسيوم بانتظام من الجهاز. إن استخدام منتجات إزالة الترسبات مناسب مع الأجهزة المنزلية.
- اشطف الغلاية عدة مرات بماء نظيف بعد إزالة الرواسب.

الضمان

- يحمل هذا المنتج ضمان لمدة 24 شهر. يعتبر هذا الضمان ساريًا طالما تم استخدام المنتج حسب التعليمات وللأغراض التي صنع من أجلها الجهاز. إضافة إلى ذلك، يجب إرسال إثبات الشراء الأصلي (فاتورة أو ورقة بيع أو إيصال) مع تاريخ الشراء واسم بائع التجارة ورقم المنتج.

البيئة



وبسبب العرض الثابت والضييق، يجب ألا يتم وضع هذا الجهاز في سلة النفايات المنزلية في نهاية عمره الافتراضي، ولكن يجب نقله إلى نقطة المركزية لإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. إن كلاً من الرمز الموجود على الجهاز، وعلل التعليمات والتعليق يحدرك من هذه المسألة الهامة. يمكن إعادة تدوير المواد المستخدمة في هذا الجهاز. من خلال إعادة تدوير الأجهزة المنزلية، فإنك تقدم إسهام هام للحفاظ على البيئة التي نعيش فيها. استمر في المساهمة الخفية عن نقطة التجميع.

الدعم

يمكنك الحصول على جميع المعلومات وقطع الغيار المتوفرة عبر الموقع الإلكتروني www.princesshome.eu

Made in China
صنع في الصين

© Princess 2019