



EN Instruction manual

AR الاستخدام



PARTS DESCRIPTION / وصف الأجزاء



[WEEE Logo]



EN Instruction manual

SAFETY

- By ignoring the safety instructions the manufacturer cannot be held responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord cannot become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the appliance unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, offices and other working environments.
 - By clients in hotels, motels and other residential type environments.
 - Bed and breakfast type environments.
 - Farm houses.

- Children shall not play with the appliance.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- If the kettle is overfilled, boiling water may be ejected.
- Do not remove the lid while the water is boiling.
- Please use the kettle only with the stand provided.
- Caution: Ensure that the kettle is switched off before removing it from its stand.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.

PARTS DESCRIPTION

- Cover
- On/Off switch
- Power indicator
- Base
- Button to open lid

BEFORE THE FIRST USE

- Take the appliance and accessories out the box. Remove the stickers, protective foil or plastic from the device.
- Place the device on a flat stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
- Before the first use boil a full kettle of water to clean the kettle and discard this water.

USE

- Always remove the kettle from the base when filling it, this to avoid water dripping into the base.
- Make sure the water level will never exceed the maximum level marker.
- If not enough water is used, the kettle will switch off, with too much water it may boil over. Switch the device on by pressing at the on/off switch. The indicator light will be illuminated. Once the water has boiled, the on/off switch returns automatically to the off position.
- If the appliance is accidentally switched on when empty, the boil-dry protection will automatically switch it off. Adding cool water will cool the boil-dry protection mechanism which enables you to use the kettle as normal.

CLEANING AND MAINTENANCE

- Before cleaning, unplug the appliance and wait for the appliance to cool down.
- Use a soft damp cloth to clean the housing of the device.
- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the appliance.
- Never immerse the kettle and base in water or any other liquids.
- The device should be regularly decalcified. Use a descaling product which is suitable for household appliances.
- Rinse the kettle several times with clean water after descaling.

WARRANTY

- This product is warrantied for 2 Years, for detailed terms, please refer to the Warranty Card.
- Following parts are not covered by warranty:
 - Knobs.
 - Any broken body parts.

Approximate life of this appliance under normal conditions is 3 Years.

For service and repairs, please call the following numbers:

United Electronics Co.
Saudi Arabia (Toll-free) 800 124 0900

ENVIRONMENT



This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

AR دليل الإرشادات

السلامة

- بتجاهل تعليمات السلامة، لا يمكن اعتبار الشركة المصنعة مسؤولة عن التلف.
- في حالة تلف سلك الإمداد بالطاقة، يجب استبداله من قبل الشركة المصنعة أو وكيل الخدمة أو الأشخاص المؤهلين بالمثل لتجنب المخاطر.
- لا تقم أبدًا بنقل الجهاز عن طريق سحب السلك وتأكد من أن السلك لا يمكن أن يتشابك.
- يجب وضع الجهاز على سطح مستو وثابت.
- يجب ألا يترك المستخدم الجهاز دون مراقبة أثناء توصيله بالتيار.
- هذا الجهاز مخصص للاستخدام في الأغراض المنزلية وللغرض المصنوع من أجله فقط.
- لا يجوز استخدام هذا الجهاز من قبل الأطفال الذين تقل أعمارهم عن 8 سنوات. يمكن استخدام هذا الجهاز من قبل الأطفال الذين تتراوح أعمارهم بين 8 سنوات وما فوق والأشخاص ذوي القدرات البدنية أو الحسية أو العقلية المنخفضة أو الأشخاص الذين لديهم نقص في الخبرة والمعرفة إذا تم تزويدهم بالإشراف أو التعليمات المتعلقة باستخدام الجهاز بطريقة آمنة ويفهم المخاطر المتضمنة. يجب عدم لعب الأطفال بالجهاز. اجعل الجهاز والسلك الخاص به بعيدين عن متناول الأطفال الذين تقل أعمارهم عن 8 سنوات. يجب عدم تنظيفه وصيانته من قبل الأطفال إلا إذا كان عمرهم أكبر من 8 سنوات ويتم الإشراف عليهم.
- لحماية نفسك من الصدمة الكهربائية، لا تغمر السلك أو المقبس أو الجهاز في المياه أو أي سائل آخر.
- هذا الجهاز مخصص للاستخدام المنزلي وللإستخدام في الأماكن المشابهة مثل:
 - أماكن مطابخ الموظفين في المتاجر والمكاتب وأماكن العمل الأخرى.
 - أو من قبل نزلاء الفنادق والإستراحات والأماكن السكنية الأخرى.
 - والأماكن التي تقدم مبيتًا ووجبة إفطار.
 - والمنازل الريفية.
- يجب على الأطفال عدم اللعب بهذا الجهاز.
- لا ينبغي استخدام هذا الجهاز من قبل الأطفال. احرص على حفظ الجهاز والسلك الخاص به بعيدًا عن متناول الأطفال.
- إذا تم ملء الغلاية حتى تفيض، قد ينسكب الماء المغلي.
- لا تقم بإزالة الغطاء أثناء غليان الماء.
- يرجى استخدام الغلاية فقط مع الحامل المرفق معها.
- احترس! تحقق من إطفاء غلاية المياه قبل إزالتها عن حامل تثبيتها.
- لحماية نفسك من التعرض إلى صدمة كهربائية، لا تغمس السلك أو القابس أو الجهاز في الماء أو في أية سوائل أخرى.

وصف الأجزاء

- غطاء
- مفتاح التشغيل/إيقاف التشغيل
- مؤشر الطاقة
- القاعدة
- زر لفتح الغطاء

قبل الاستخدام الأول

- قم بإخراج الجهاز والملحقات خارج العبوة. قم بإزالة الملصقات، أو البلاستيك أو ورق الأومنيوم الواقي عن الجهاز.
- ضع الجهاز على سطح ثابت مستو وتأكد من وجود حد أدنى من المساحة الخالية حول الجهاز قدرها 10 سم. هذا الجهاز غير مناسب للتثبيت في خزانة أو للاستخدام الخارجي.
- قبل الاستخدام الأول قم بغلي غلاية مملوءة بالكامل بالماء لتنظيف الغلاية ثم تخلص من هذا الماء.

الاستخدام

- قم دائمًا بإزالة الغلاية من القاعدة عند ملئها، لتجنب تساقط المياه على القاعدة.
- تأكد من أن مستوى المياه لا يتجاوز علامة الحد الأقصى.
- إذا لم يتم استخدام مياه كافية، ستتوقف الغلاية عن التشغيل، بينما في حالة وضع الكثير من المياه قد ينسكب من الغلاية. قم بتشغيل الجهاز من خلال الضغط على مفتاح التشغيل/الإيقاف. ستضيء لمبة المؤشر. بمجرد أن يغلي الماء، سيموت مفتاح التشغيل/إيقاف التشغيل/توميكيكا إلى وضع إيقاف التشغيل. إذا تم تشغيل الجهاز عن طريق الخطأ وهو فارغ، ستقوم خاصية الحماية من الغليان الجاف أوميكاكا بإيقاف تشغيل الغلاية. إن إضافة الماء البارد ستمثل على تبريد آلية الحماية من الغليان الجاف والتي ستمكّنك من استخدام الغلاية كالمعتاد.

التنظيف والصيانة

- قبل التنظيف، اصلب الجهاز من المقبس وانتظر حتى يبرد الجهاز.
- استخدم قطعة قماش ناعمة ورطبة لتنظيف غلاف الجهاز.
- نظف الجهاز باستخدام قطعة قماش مبللة. لا تستخدم أبدًا منظفات قوية أو شديدة التركيز أو لبادات تلميع أو ليفة معدنية، والتي قد تلحق ضررًا بالجهاز.
- احرص ألا تغمس الغلاية والقاعدة أبدًا في الماء أو أي سائل آخر.
- يجب إزالة الكالسيوم بانتظام من الجهاز. إن استخدام منتجات إزالة الترسبات مناسبة مع الأجهزة المنزلية.
- اشطف الغلاية عدة مرات بماء نظيف بعد إزالة الرواسب.

ضمان

- هذا الجهاز مضمون لمدة عامين. لمعرفة أحكام الضمان يرجى قراءة كرت ضمان المنتج.
- المكونات أدناه غير مشمولة بالضمان:
 - المقابض.

– أجزاء البدن القابلة للتكسر.

العمر الافتراضي للجهاز يعتمد على ظروف التشغيل العادية. العمر الافتراضي 3 سنوات تقريبا.
يرجى الاتصال على أرقام خدمة الصيانة والتصليح الآتية:
الشركة المسجلة للإلكترونيات

المملكة العربية السعودية (الهاتف المجاني) 800 124 0900

البينة



لا ينبغي وضع هذا الجهاز في قمامة المنزل في نهاية مثته، ولكن يجب تعميمه في أي نقطة مركزية تقوم بإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. يقوم هذا الرمز الموجود على الجهاز ودليل التعليمات والتعبئة بلفت انتباهك إلى هذه المشكلة المهمة. يمكن إعادة تدوير الأجزاء المستخدمة في هذا الجهاز. عن طريق إعادة تدوير الأجهزة المنزلية المستخدمة، فإنك تساهم في دفع عجلة حماية بيئتنا. أسأل السلطات المحلية للحصول على معلومات بشأن القطعة التي تقوم بإعادة التدوير.

Made in China
صنع في الصين

© Princess 2023