



EN Instruction manual

الاستخدام



Made in China
صنع في الصين

Coffee Grinder

مطحنة بن

01.242195.04.001

وصف الأجزاء / PARTS DESCRIPTION



EN Instruction manual

SAFETY

- By ignoring the safety instructions the manufacturer can not be hold responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- Do not allow children to use the device without supervision.
- Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
- Always disconnect the device from the supply if it is left unattended and before assembling, disassembling or cleaning.
- It is absolutely necessary to keep this appliance clean at all times, because it comes into direct contact with food.
- NOTE: The chopping blades are very sharp, avoid physical contact during emptying and cleaning the device, you can seriously injure.
- This appliance is intended to be used in household and similar applications such as:

- Staff kitchen areas in shops, offices and other working environments.
- By clients in hotels, motels and other residential type environments.
- Bed and breakfast type environments.
- Farm houses.

PARTS DESCRIPTION

- On/Off switch
- Transparent lid
- Motor unit
- Reservoir

BEFORE THE FIRST USE

- Take the appliance and accessories out the box. Remove the stickers, protective foil or plastic from the device.
- Put the power cable into the socket. (Note: Make sure the voltage which is indicated on the device matches the local voltage before connecting the device. Voltage 220V-240V 50/60Hz)
- Place the appliance on a stable surface and make sure there is 10 cm. free of space around the appliance.
- Wash lid in warm soapy water. Be sure to rinse and dry the lid thoroughly.
- Wipe the motor unit with a moist cloth.
- Do not immerse the motor unit in water or any other liquid.
- Do not put the motor unit neither one of the parts in the dishwasher.

USE

- Pour the desired volume of beans into the reservoir. Note: maximum 60 grams
- Place the reservoir into the appliance.
- Screw the lid on the device and close firmly into place until you hear a click. Note: this unit is equipped with a safety switch, when the lid is not properly installed, the device will not function.
- Insert the plug into the socket. Press the on / off button pulsing, until the beans have reached the desired fineness.
- Note: do not use the device more than 30 seconds contiguous.
- After use, disconnect the plug.

CLEANING AND MAINTENANCE

- The lid and reservoir can be cleaned with warm water and mild detergent. The motor unit can be cleaned by using a damp cloth.
- Do not put any parts in the dishwasher. Never immerse the motor unit in water.
- Make sure all parts are dried thoroughly.

GUARANTEE

- This product is guaranteed for 24 months granted. Your warranty is valid if the product is used in accordance to the instructions and for the purpose for which it was created. In addition, the original purchase (invoice, sales slip or receipt) is to be submitted with the date of purchase, the name of the retailer and the item number of the product.

ENVIRONMENT

- This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

AR دليل الإرشادات

السلامة

- عند إهمال تعليمات السلامة لا تتحمل الشركة المصنّعة أية مسؤولية عن وقوع تلفيات.
- في حالة تلف سلك الإمداد بالطاقة، يجب استبداله بواسطة الشركة المصنّعة أو وكيل الصيانة أو أي فني مؤهل لتجنب التعرض إلى المخاطر.
- لا تحرك الجهاز مطلقاً عن طريق سحب السلك، وتأكد من أن السلك لن يصبح متشابكاً.
- يجب وضع الجهاز على سطح ثابت ومستو.
- تم تصميم هذا الجهاز للاستخدام المنزلي فقط وللأغراض التي صُنع من أجلها.
- ينبغي عدم استخدام هذا الجهاز بواسطة أطفال أصغر من 8 سنوات. يمكن استخدام هذا الجهاز بواسطة الأطفال من سن 8 سنوات وما فوق والأشخاص ذوي القدرات الجسدية أو الحسية أو العقلية المحدودة أو الذين يفتقرون إلى الخبرة والمعرفة إذا تم الإشراف عليهم أو إرشادهم بشأن كيفية استخدام الجهاز بطريقة آمنة وفهمهم للمخاطر المحتملة. يجب على الأطفال عدم اللعب بهذا الجهاز. احرص على بقاء الجهاز والسلك بعيدين عن متناول الأطفال أقل من 8 سنوات. يجب على الأطفال عدم القيام بعملية التنظيف وصيانة المستخدم إلا إذا كانوا أكبر من 8 سنوات وفي وجود من يشرف عليهم.
- لحماية نفسك من التعرض إلى صدمة كهربائية، لا تمس السلك أو القابس أو الجهاز في الماء أو في أية سواكل أخرى.
- لا تسمح للأطفال باستخدام الجهاز بدون الإشراف عليهم.
- قم بإيقاف الجهاز وفصله عن مصدر الطاقة قبل تغيير الملحقات أو الاقتراب من الأجزاء المتحركة المستخدمة.
- قم دائماً بفصل الجهاز عن مصدر الطاقة في حالة تركه بدون مراقبة أو قبل التركيب أو الفك أو التنظيف.
- من الضروري للغاية الحفاظ على هذا الجهاز نظيف طوال الوقت، لأنه يلامس الطعام بشكل مباشر
- ملاحظة: إن شفرات الفرم حادة للغاية، لذلك تجنب ملامستها الجسم أثناء تفريغ الجهاز أو تنظيفه، لأن ذلك قد يصيبك بجرح بالغ.
- هذا الجهاز مخصص للاستخدام المنزلي وللإستخدام في الأماكن المشابهة مثل:
 - أماكن مطابخ للموظفين في الفنادق والمكاتب وأماكن العمل الأخرى.
 - أو من قبل زلاء الفنادق والاستراحات والأماكن السكنية الأخرى.
 - والأماكن التي تقدم ميثاً ووجبة إفطار.
 - والمنازل الريفية.

وصف الأجزاء

- مفتاح التشغيل/إيقاف التشغيل
- غطاء شفاف
- وحدة الحرك
- الخزان

قبل الاستخدام الأول

- قم بإخراج الجهاز والملحقات خارج العلبة. قم بإزالة للشفقات، أو البلاستيك أو ورق الأومنيوم الواقي عن الجهاز.
- ضع كابل الطاقة في المنفذ. (ملاحظة: تأكد أن الجهد الكهربائي المتأثر إليه على الجهاز مطابق للجهد المحلي قبل توصيل الجهاز. الجهد الكهربائي 220-240 فولت. 50/60 هرتز)
- ضع الجهاز على سطح ثابت وتأكد من وجود مساحة خالية حول الجهاز قدرها 10 سم.
- قم بغسل الغطاء ماء دافئ وصابون. تأكد من شطف الغطاء وتجفيفه جيداً.
- امسح وحدة الحرك بقطعة قماش رطبة.
- لا تمس وحدة الحرك في الماء أو أية سواكل أخرى.
- لا تضع وحدة الحرك أو أي من الأجزاء في غسالة الأطباق.

الاستخدام

- قم بوضع كمية الحبوب المطلوبة داخل الخزان. ملاحظة: الحد الأقصى المسموح به 60 جرام.
- ضع الخزان في الجهاز.
- قم ب تثبيت الغطاء في الجهاز وأفلقه بإحكام في مكانه حتى تسمع صوت طقطقة. ملاحظة: تم تجهيز هذه الوحدة بفتاح أمان، في حالة عدم تركيب الغطاء بشكل غير صحيح، لن يعمل الجهاز.
- أدخل القابس في مقبس، اضغط على زر التشغيل/الإيقاف حتى تصل الحبوب إلى القوام المطلوب.
- ملاحظة: لا تستخدم الجهاز لفترة تزيد عن 30 ثانية متواصلة.
- بعد الاستخدام، افصل الجهاز من القابس.

التنظيف والصيانة

- يمكن تنظيف الغطاء والخزان ماء دافئ ومطّيف معتدل. يمكن تنظيف وحدة الحرك باستخدام قطعة قماش رطبة.
- لا تضع أي جزء من الأجزاء في غسالة الأطباق. لا تعمر وحدة الحرك مطلقاً في الماء.
- تأكد من جفاف جميع الأجزاء تمامًا.

الضمان

- يتمل هذا المنتج ضمان لمدة 24 شهر. يعتبر هذا الضمان سارياً طالما تم استخدام المنتج حسب التعليمات وللأغراض التي صنع من أجلها الجهاز. إضافة إلى ذلك، يجب إرسال إثبات الشراء الأصلي (فاتورة أو ورقة بيع أو إيصال) مع تاريخ الشراء واسم بائع التجزئة ورقم المنتج.

البيئة



- وبسبب العرض الثابت والضيّق، يجب ألا يتم وضع هذا الجهاز في سلة النفايات المنزلية في نهاية عمره الافتراضي، ولكن يجب تقديمه إلى نقطة المركزية لإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. إن كلاً من الرمز الموجود على الجهاز، و دليل التعليمات والتعليق بحدوث تدوير هذه السلسلة، يمكن إعادة تدوير المواد المستخدمة في هذا الجهاز. من خلال إعادة تدوير الأجهزة المنزلية، فإنك تقدم إسهام هام للحفاظ على البيئة التي نعيش فيها. استفسر من السلطات المحلية عن نقطة التجميع.