



Digital Aerofryer XL
01.182020.01.001

PARTS DESCRIPTION / OSIEN KUVAUKSET



[WEEE Logo]



EN Instruction manual

SAFETY

- By ignoring the safety instructions the manufacturer can not be held responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- This appliance is only to be used for household purposes and only for the purpose it is made for. In worst case the food can catch fire. (i.e. do not use more than one tea spoon of oil, no meat that will release to much grease or water intended for boiling foods).
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- The appliance is to be connected to a socket-outlet having an earthed contact (for class I appliances).
- WARNING:** If the surface is cracked, switch off the appliance to avoid the possibility of an electric shock.
- Keep the appliance and its cord out of reach of children less than 8 years.
- The temperature of accessible surfaces may be high when the appliance is operating.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.

- Surfaces indicated with this logo are liable to get hot during use.**
- In order to prevent disruptions of the airflow do not put anything on top of the appliance and make sure there is always 10 centimeter of free space around the appliance.
- After the baking process the appliance needs to cool down, this cooling process will activate automatically when the timer is done. Avoid to unplug the appliance from the net socket before the cooling process is finished because the remaining hot air can damage the appliance.
- This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, offices and other working environments.
 - By clients in hotels, motels and other residential type environments.
 - Bed and breakfast type environments.
 - Farm houses.

SAVE THESE INSTRUCTIONS HOUSEHOLD USE ONLY

PARTS DESCRIPTION

1	Timer control buttons	12	Fish button
2	Temperature control buttons	13	LCD display
3	Start button	14	Basket
4	Cancel button	15	Basket release button
5	Warm-up button	16	Basket handle
6	Chips button	17	Pan
7	Chicken button	18	Air inlet
8	Steak button	19	Hot Air outlet openings
9	Shrimp button	20	Mains cord
10	Meat button	21	Grill Rack
11	Cake button		

BEFORE THE FIRST USE

- Remove all packaging material.
- Remove any stickers or labels from the appliance.
- Thoroughly clean the basket and the pan with hot water, some washing-up liquid and a non-abrasive sponge.
- Wipe the inside and outside of the appliance with a moist cloth.
- Place the appliance on a stable, horizontal and level surface, do not place the appliance on non-heat-resistant surfaces.
- Place the basket in the pan properly

- This is an air fryer that works on hot air. Do not fill the pan with oil or frying fat.
- In order to prevent disruptions of the airflow do not put anything on top of the appliance and make sure there is always 10 centimeter of free space around the appliance.
- NOTE:** After the baking process the appliance needs to cool down, this cooling process will activate automatically when the timer is done. Please avoid to unplug the appliance from the net-socket before the cooling process is finished because the remaining hot air can damage the appliance.

USE

- Put the mains plug in an earthed wall socket.
- Carefully pull the pan out of the air fryer.
- Put the ingredients in the basket.
- Slide the pan back into the air fryer.
- Never use the pan without the basket in it.
- Do not touch the pan during and some time after use, as it gets very hot. Only hold the pan by the handle.
- When the pan is cold, please use the warm-up function first, by pressing the warm-up function button. The device will warm up for 5 minutes on a temperature of 80 degrees. After this, the device is ready for use.
- There are 7 seven frying programs included: CHIPS, CHICKEN, STEAK, SHRIMP, MEAT, CAKE, and FISH. Use the corresponding function button depending on the type of food you wish to prepare.
- When you press the function button, the aerofryer will start the corresponding program. When you have chosen the wrong program, you can abort by pressing the cancel button. The device will stop after 20 seconds. After this you can select another function. It is also possible to adjust the chosen program by changing the time and temperature.
- The time can be adjusted with the timer control buttons. Press the timer control buttons one time to increase or decrease the frying time by one minute. Press and hold one of the buttons to adjust the time faster. You can set the timer between 1 and 30 minutes.
- The temperature can be adjusted with the temperature control buttons. Press the temperature control buttons one time to increase or decrease the temperature by 5 degrees. Press and hold one of the buttons to adjust the temperature faster. You can set the temperature between 80 and 200 degrees.
- It is also possible to start the device without selecting a function. Set the time and temperature with the timer and temperature control buttons, then press the start button.
- You can pause any program by pressing the start button, for example if you want to shake your ingredients. The device will pause after 20 seconds. To resume the frying process, press the start button again.
- When you pull out the pan during the frying process, the device will shut off automatically within 5 seconds. When you reinsert the device, the program will resume.
- To cancel any program, press the cancel button. The device will shut off after 20 seconds.
- During the hot air frying process, the heating-up light comes on and goes off from time to time. This indicates that the heating element is switched on and off to maintain the set temperature.
- Excess oil from the ingredients is collected on the bottom of the pan. Some ingredients require shaking halfway through the preparation time. To shake the ingredients, pull the pan out of the appliance by the handle and shake it. Then slide the pan back into the air fryer. Do not press the basket release button during shaking.
- When you hear the timer beep 5 times, the set preparation time has elapsed. The device will shut off after 20 seconds. Pull the pan out of the appliance and place it on a heat-resistant surface.
- Check if the ingredients are ready. If the ingredients are not ready yet, simply slide the pan back into the appliance and set the timer to a few extra minutes.
- To remove small ingredients (e.g. fries), press the basket release button and lift the basket out of the pan. Do not turn the basket upside down with the pan still attached to it, as any excess oil that has collected on the bottom of the pan will leak onto the ingredients.
- Empty the basket into a bowl or onto a plate. When a batch of ingredients is ready, the air fryer is instantly ready for preparing another batch.
- Tips**
- Shaking smaller ingredients halfway during the preparation time optimizes the end result and can help prevent unevenly fried ingredients.
- Add some oil to fresh potatoes for a crispy result. Fry your ingredients in the air fryer within a few minutes after you've added the oil.
- Do not prepare extremely greasy ingredients such as sausages in the air fryer.
- Place a baking tin or oven dish in the basket if you want to bake a cake or quiche or if you want to fry fragile ingredients or filled ingredients.
- You can also use the air fryer to reheat ingredients. To reheat ingredients, set the temperature to 150°C for up to 10 minutes.

CLEANING AND MAINTENANCE

- Before cleaning, unplug the appliance and wait for the appliance to cool down.
- Never immerse the device in water or any other liquid. The device is not dishwasher proof.
- Clean the pan and basket with hot water, some washing-up liquid and a non-abrasive sponge. The pan and basket are not dishwasher-proof.
- If dirt is stuck to the basket or the bottom of the pan, fill the pan with hot water with some washing-up liquid. Put the basket in the pan and let the pan and the basket soak for about 10 minutes.
- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.

ENVIRONMENT



- This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

Support

You can find all available information and spare parts at www.princesshome.eu

FI Ohjekirja

TURVALLISUUS

- Jos turvallisuusohjeita ei noudateta, valmistaja ei ole vastuussa vahingoista.
- Jos virtajohto vaurioituu, tulee valmistajan, huoltoedustajan tai vastaavan pätevyyden haltijan vaihtaa se, jotta vältytään sähköiskun vaaralta.
- Älä koskaan siirrä laitetta vetämällä johdosta ja varmista, ettei johto sotkeennu.
- Laitte on asetettava vakaalle, tasaiselle alustalle.
- Laitetta saa käyttää vain kotitalousien tarpeisiin ja vain sen alkuperäiseen käyttötarkoitukseen. Pahimmassa tapauksessa ruoka voi syttyä tuleen. (Älä käytä enempää kuin yksi teelusikallinen öljyä, äläkä lihaa, joka vapauttaa paljon rasvaa tai ruoan keittämiseen tarkoitettua vettä.)

- Alle 8-vuotiaat lapset eivät saa käyttää tätä laitetta. Tätä laitetta saavat käyttää 8-vuotiaat ja sitä vanhemmat lapset sekä henkilöt, joilla on fyysisiä, aistillisia, henkisiä tai liikkuvuuteen liittyviä rajoitteita, tai joilla on puutteellinen kokemus tai tuntemus, mikäli heitä valvotaan ja ohjataan laitteen turvallisessa käytössä ja he ymmärtävät siihen liittyvät vaarat. Lapset eivät saa leikkiä laitteella. Pidä laite ja sen virtajohto alle 8-vuotiaiden lasten ulottumattomissa. Lapset eivät saa puhdistaa tai suorittaa käyttäjähuoltoa laitteelle, elleivät he ole yli 8-vuotiaita ja valvottuina.
- Sähköiskujen välttämiseksi älä upota johtoa, pistoketta tai laitetta veteen tai muuhun nesteeseen.
- Laitte on liitettävä maadoitettuun pistorasiaan (luokan I laitteilla).
- VAROITUS: Jos pinta on haljennut, kytkä laite pois päältä sähköiskumahdollisuuden välttämiseksi.
- Pidä laite ja sen virtajohto alle 8-vuotiaiden lasten ulottumattomissa.
- Käyttöpinnat voivat kuumentua laitteen käytön aikana.
- Laitetta ei ole tarkoitettu käytettäväksi ulkoisella ajastimella tai erillisellä kauko-ohjauksjärjestelmällä.

- Tässä loogossa näytetyt pinnat tulevat kuumiksi käytön aikana.**
- Älä estä ilmavirtausta laittamalla jotain laitteen päälle ja pidä aina vähintään 10 cm vapaata tilaa laitteen ympärillä.
- Leivonnan jälkeen laitteen on annettava jäähtyä. Tämä jäähtymisprosessi käynnistyy automaattisesti ajastinajan päätyttyä. Älä irrota virtapistoketta pistorasiasta ennen jäähtymisen päättymistä, sillä jäljelle jäävä kuuma ilma voi vaurioittaa laitetta.
- Tämä laite on tarkoitettu käytettäväksi kotitalouksissa ja samankaltaisissa ympäristöissä, kuten:
 - Henkilöstön keittiötiloissa kaupoissa, toimistoissa ja muissa työympäristöissä.
 - Asiakkaiden käytössä olevissa tiloissa hotelleissa, motelleissa ja muissa asuinympäristöissä.
 - Majoituksen ja aamiaisen tarjoavissa ympäristöissä.
 - Maatiloissa.

SÄILYTÄ NÄMÄ OHJEET VAIN KOTITALOUSKÄYTTÖÖN

OSIEN KUVAUKSET

1	Ajastimen säätöpainikkeet	12	Kala-painike
2	Lämpötilan säätöpainikkeet	13	LCD-näyttö
3	Käynnistä-painike	14	Kori
4	Peruuta-painike	15	Korin vapautuspainike
5	Lämmityksen painike	16	Korin kahva
6	Ranskalaiset perunat -painike	17	Pannu
7	Kana-painike	18	Ilman tuloliitin
8	Pihvi-painike	19	Ilman ulostuloaukot
9	Katkarapu-painike	20	Virtajohto
10	Liha-painike	21	Grillausritilä
11	Kakku-painike		

ENNEN ENSIMMÄISTÄ KÄYTTÖÄ

- Poista kaikki pakkausmateriaali.
- Poista kaikki tarrat ja etiketit laitteesta.
- Puhdista kori ja pannu läpikotaisin kuumalla vedellä, nestemäisellä pesuaineella ja hankaamattomalla sienellä.
- Pyyhi laitteen sisä- ja ulkopuoli kostealla liinalla.
- Aseta laite vakaalle, vaakasuoralle pinnalle. Älä aseta laitetta kuumuutta kestävämmille pinnoille.
- Aseta kori pannuun asianmukaisesti.
- Tämä on kuumalla ilmalla toimiva ilma-astin. Älä täytä pannua öljyllä tai paistarasvalla.
- Ilmavirtauksen varmistamiseksi älä aseta esineitä laitteen päälle ja huolehdi siitä, että laitteen ympärillä on aina vähintään 10 cm vapaata tilaa.
- HUOMAA:** Leivonnan jälkeen laitteen on annettava jäähtyä. Jäähtymisprosessi käynnistyy automaattisesti ajastinajan päätyttyä. Älä irrota virtapistoketta pistorasiasta ennen jäähtymisen päättymistä, sillä jäljelle jäävä kuuma ilma voi vaurioittaa laitetta.

KÄYTTÖ

- Laita virtapistoke maadoitettuun pistorasiaan.
- Vedä varovasti pannu ulos ilma-astimesta.
- Aseta ainekset koriin.
- Liuta pannu takaisin ilma-astimeen.
- Älä koskaan käytä pannua ilman, että siinä on kori.
- Älä koske pannuun käytön aikana ja jonkin aikaa käytön jälkeen, sillä pannu tulee hyvin kuumaksi. Pidä pannusta kiinni vain kädensijasta.
- Kun pannu on kymä, käytä ensin lämmitystoimintoa painamalla lämmitystoiminto-painiketta. Laitte lämpenee 5 minuuttia 80 asteen lämpötilassa. Laitte on käyttövalmis tämä jälkeen.
- Laitteessa on seitsemän (7) paisto-ohjelmaa: RANSKALAISET, KANA, PIHVI, KATKARAPU, LIHA, KAKKU ja KALA. Käytä valmistamallasi ruualle sopivaa toimintopainiketta.

- Painaessasi ohjelmopainiketta ilma-astin käynnistää vastaavan ohjelman. Jos olet valinnut väärän ohjelman, voit peruuttaa ohjelman painamalla peruutuspainiketta. Laitte pysähtyy 20 sekunnin jälkeen. Tämän jälkeen voit valita uuden toiminnon. Valitun ohjelman säätämiseen on myös mahdollista muuttamalla aikaa ja lämpötilaa.
- Voit säätää aikaa ajastimen säätöpainikkeilla. Lisää tai vähennä paistoaikaa yhdellä minuutilla painamalla ajastimen säätöpainikkeita yhden kerran. Säädä aikaa nopeammin pitämällä säätöpainiketta painettuna. Voit asettaa ajastimen ajaksi 1 - 30 minuuttia.
- Voit säätää lämpötilaa lämpötilan säätöpainikkeilla. Lisää tai vähennä lämpötilaa 5 astetta painamalla lämpötilan säätöpainikkeita yhden kerran. Säädä lämpötilaa nopeammin pitämällä säätöpainiketta painettuna. Voit asettaa lämpötilaksi 80 - 200 astetta.
- Laitte voidaan myös käynnistää valitsematta toimintoa. Aseta aika ja lämpötila ajastimen ja lämpötilan säätöpainikkeilla ja paina sitten käynnistyspainiketta.
- Voit keskeyttää minkä tahansa ohjelman painamalla käynnistyspainiketta, esim. ainesten ravistelemiseksi. Laitte menee taukotilaan 20 sekunnin jälkeen. Jatka paistoprosessia painamalla käynnistyspainiketta uudelleen.
- Jos vedät pannun ulos paistoprosessin aikana laite sammuu automaattisesti 5 sekunnin kuluessa. Ohjelma jatkuu, kun työnnyt laitteen takaisin paikalleen.
- Voit peruuttaa minkä tahansa ohjelman painamalla peruutuspainiketta. Laitte sammuu 20 sekunnin jälkeen.
- Kuumailmapaistoprosessin aikana lämmityksen merkivalo syttyy ja sammuu ajoittain. Tämä osoittaa lämmitysvaustuksen kytkeytymisen päälle ja pois asetetun lämpötilan ylläpitämiseksi.
- Liika öljy aineksista kerätään pannun pohjalle.
- Jotkut ainekset edellyttävät ravistelua valmistuksen puolivälissä. Ravistele aineksia vetämällä pannu ulos laitteesta kahvaa käyttäen ja ravistele pannua. Liu'uta sitten pannu takaisin ilma-astimeen. Älä paina koriin vapautuspainiketta ravistelun aikana.
- Kun kuulet ajastimen piippaavan 5 kertaa, asetettu valmistusaika on kulunut loppuun. Laitte sammuu 20 sekunnin jälkeen. Vedä pannu ulos laitteesta ja aseta se lämpöä kestäväälle alustalle.
- Tarkista ainesten olevan valmiita. Jos ainekset eivät ole vielä valmiita, tyhjännä kori maljaan tai lautaselle. Aineesart ollessa valmis ilma-astin on välittömästi valmis seuraavaan erän valmistukseen.
- Vinkit
- Pienempien ainesten ravistelu valmistuksen puolivälissä optimoi lopputuloksen ja voi auttaa estämään epätasaisesti paistuneet ainekset.
- Lisää hieman öljyä tuoreisiin perunoihin rapean lopputuloksen saamiseksi. Paista ainekset ilma-astinissä muutaman minuutin kuluessa öljyn lisäämisen jälkeen.
- Älä valmista ilma-astinissä erittäin rasvaisia aineksia, kuten makkaraita.
- Aseta paisto- tai uuniastia koriin, jos haluat valmistaa kakun tai piirakan tai jos haluat valmistaa arkoja aineksia tai täytettyjä aineksia.
- Voit käyttää ilma-astintta myös ainesten lämmittämiseen uudelleen. Lämmitä ainekset uudelleen asettamalla lämpötilaksi 150 °C ja ajaksi 10 minuuttia.

PUHDISTUS JA YLLÄPITO

- Ennen puhdistusta irrota laite sähköverkosta ja odota, että laite viilenee.
- Älä koskaan upota laitetta veteen tai muuhun nesteeseen. Laitte ei kestä konepesua.
- Puhdista kori ja pannu kuumalla vedellä, nestemäisellä pesuaineella ja hankaamattomalla sienellä. Pannu ja kori eivät ole konepesun kestäviä.
- Jos likaa on tarttunut kiinni koriin tai pannun pohjalle, täytä pannu kuumalla vedellä ja nestemäisellä pesuaineella. Aseta kori pannuun ja liota pannua ja koria noin 10 minuuttia.
- Puhdista laite kostealla pyyhkeellä. Älä käytä vahvoja tai hankaavia puhdistusaineita, hankaustynyä tai teräsvillaa, jotka voivat vahingoittaa laitetta.

YMPÄRISTÖ



- Tätä laitetta ei saa hävittää talousjätteiden mukana sen elinkaaren lopussa. Se on sen sijaan vietävä sähkö- ja elektroniikkalaitteiden kierrätyskeskukseen. Laitteessa, käyttöoppaassa ja pakkaussessa oleva symboli korostaa tätä tärkeää seikkaa. Tämän laitteen valmistusmateriaalit voidaan kierrättää. Kierrättämällä käytetyt talouslaitteet myötävaikuttavat tärkeään pyrkimykseen suojella ympäristöämme. Kysy paikallisilta viranomaisilta lisätietoja keräyspisteestä.

Tuki

Tiedot ja varaosat löydät osoitteesta: www.princesshome.eu