



Made in China
صنع في الصين
220-240V / 50/60Hz / 160W

Champion Juicer
عصاراة البطل
01.201852.09.001

PARTS DESCRIPTION / وصف الأجزاء



[WEEE Logo]



EN Instruction manual

SAFETY

- By ignoring the safety instructions the manufacturer can not be held responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- Do not allow children to use the device without supervision.
- Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
- Always disconnect the device from the supply if it is left unattended and before assembling, disassembling or cleaning.
- It is absolutely necessary to keep this appliance clean at all times, because it comes into direct contact with food.
- This appliance is intended to be used in household and similar applications such as:
 - Staff kitchen areas in shops, offices and other working environments.
 - By clients in hotels, motels and other residential type environments.
 - Bed and breakfast type environments.
 - Farm houses.

PARTS DESCRIPTION

- Press handle
- Fruit dome
- Press cone
- Pulp sieve
- Reservoir
- Juice spout
- Motor Axis

BEFORE THE FIRST USE

- Take the appliance and accessories out of the box. Remove the stickers, protective foil or plastic from the device.
- Before using your appliance for the first time, wipe off all removable parts with a damp cloth. Never use abrasive products.
- Connect the power cable to the socket. (Note: Make sure the indicated voltage on the device matches the local voltage before connecting the device. Voltage 220V-240V 50-60Hz.

USE

- As soon as the half citrus fruit is pressed onto the juice cone, the motor will be activated.
- Place a suitable glass under the spout of the reservoir. The spout can be pushed down to the juice to anticipate, and be folded up for the anti-drip feature. Do not exert too much pressure on the juice cone. If the sound of the motor increases significantly or the motor itself slows down dramatically, this means too much pressure has been exerted.
- Please do not run the juicer for longer than 15 seconds without interruption, please take a break for 10 minutes after pressing 10 pieces of oranges.
- Note that this appliance is equipped with an overheat protection which will turn off the device when the temperature gets too high. Once the appliance is cooled down, the thermostat will automatically be reset

CLEANING AND MAINTENANCE

- Unplug the appliance. Use a soft, slightly damp cloth to wipe appliance surfaces. Do not allow water or any other liquid to get into the unit.
- Components that have come into contact with food can be cleaned in soapy water.
- Do not use any abrasive detergent or steel wool to clean the appliance, as it may scratch the surfaces.
- The components are suitable for cleaning in a dishwasher.
- The pressure section of the handle can be easily assembled for cleaning.

WARRANTY

- This product is warranted for 2 Years, for detailed terms, please refer to the Warranty Card.
- Following parts are not covered by warranty:
 - Knobs.
 - Any broken body parts.

Approximate life of this appliance under normal conditions is 3 Years.

For service and repairs, please call the following numbers:

United Electronics Co.
Saudi Arabia (Toll-free) 800 124 0900

ENVIRONMENT



This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

Support

You can find all available information and spare parts at www.princesshome.eu

AR دليل الإرشادات

- السلاطة
- عند إهمال تعليمات السلامة لا تتحمل الشركة المصنعة أية مسؤولية عن وقوع تلفيات.
- في حالة تلف سلك الإمداد بالطاقة، يجب استبداله بواسطة الشركة المصنعة أو وكيل الصيانة أو أي فني مؤهل لتجنب التعرض للمخاطر.
- لا تحرك الجهاز مطلقاً عن طريق سحب السلك، وتأكد من أن السلك لن يصبح متشابكاً.
- يجب وضع الجهاز على سطح ثابت ومستو.
- يجب ألا يغفل المستخدم عن الجهاز أثناء توصيله بالكهرباء
- تم تصميم هذا الجهاز للاستخدام المنزلي فقط وللأغراض التي صُنع من أجلها.
- ينبغي عدم استخدام هذا الجهاز بواسطة أطفال أصغر من 8 سنوات. يمكن استخدام هذا الجهاز بواسطة الأطفال من سن 8 سنوات وما فوق والأشخاص ذوي القدرات الجسدية أو الحسية أو العقلية المحدودة أو الذين يفتقرون إلى الخبرة والمعرفة إذا تم الإشراف عليهم أو إرشادهم بشأن كيفية استخدام الجهاز بطريقة آمنة وفهمهم للمخاطر المحتملة. يجب على الأطفال عدم اللعب بهذا الجهاز. احرص على بقاء الجهاز والسلك بعيدين عن متناول الأطفال أقل من 8 سنوات. يجب على الأطفال عدم القيام بعملية التنظيف وصيانة المستخدم إلا إذا كانوا أكبر من 8 سنوات وفي وجود من يشرف عليهم.
- حماية نفسك من التعرض إلى صدمة كهربائية، لا تعمس السلك أو القابس أو الجهاز في الماء أو في أية سوائل أخرى.
- لا تسمح للأطفال باستخدام الجهاز بدون الإشراف عليهم.
- قم بإيقاف الجهاز وفصله عن مصدر الطاقة قبل تغيير الملحقات أو الاقتراب من الأجزاء المتحركة المستخدمة.
- قم دائماً بفصل الجهاز عن مصدر الطاقة في حالة تركه بدون مراقبة أو قبل التركيب أو الفك أو التنظيف.
- من الضروري للغاية الحفاظ على هذا الجهاز نظيف طوال الوقت، لأنه يلامس الطعام بشكل مباشر
- هذا الجهاز مخصص للاستخدام المنزلي وللإستخدام في الأماكن المشابهة مثل:
 - أماكن مطابخ الموظفين في المطاعم والمكاتب وأماكن العمل الأخرى.
 - أو من قبل نزلاء الفنادق والاستراحات والأماكن السكنية الأخرى.
 - والأماكن التي تقدم مينا ووجبة إفطار.
 - والشارال الريفية.

وصف الأجزاء

- مقبض الضغط
- حاجز الضغط الخاص بالضغط
- قمم الضغط
- ممشاة اللب
- الخزان
- نوهة العصار
- المحور

قبل الاستخدام الأول

- قم بإخراج الجهاز والملحقات خارج العلبة. قم بإزالة الملصقات أو البلاستيك أو ورق الأوكسوم الورقي عن الجهاز.
- قبل الاستخدام الأول، قم بتفحص جميع الأجزاء القابلة للإزالة بقلمة قماش رطبة. لا تستخدم مطلقاً آلة شحذات كاشطة.
- ضغ قبل الطاقة في المقبس (ملاحظة: تأكد من أن الجهد الذي يشار إليه على الجهاز يتطابق مع الجهد المحلي قبل توصيل الجهاز. الجهد 220 فولت -240 فولت 50-60 هرتز)

الاستخدام

- مجرد الضغط على نصف قرصة الفاكهة الحظيئة في هيكل العصار، سيتم تشغيل الموتور.
- ضغ كوب زجاجي مناسب تحت نوهة الخزان. يمكن في النوهة لأسفل لتفريغ العصار، ويمكن شحذها لأعلى لمنع التسقيط. لا تقم بضغط بشدة على قمم العصاراة. إذا ارتفع صوت الموتور بشكل ملحوظ أو تأطأ الموتور نفسه بشكل كبير، فإن هذا يعني أنه قد شحط عليه بشدة.
- يرجى عدم تشغيل العصاراة لمدة تزيد عن 15 ثانية دون توقف، يرجى إيقاف تشغيل العصاراة لمدة 10 دقائق بعد عصار 10 قطع برتقال.
- لاحظ أن هذا الجهاز مزود بحماية من فرط التسخين والتي تقوم بإيقاف تشغيل الجهاز عند ارتفاع درجة حرارته كثيراً. بمجرد أن يبرد الجهاز، سيبدأ ضبط الترموستات تلقائياً

التنظيف والصيانة

- فصل الجهاز عن مصدر التيار. استخدم قطعة قماش ناعمة ومبللة قليلاً لمسح أسطح الجهاز. لا تسمح بوصول الماء أو أية سوائل أخرى داخل الجهاز
- يمكن تنظيف المكونات التي تلامس الغذاء مباشرة بماء وصابون.
- لا تستخدم أي مسطحات كاشطة أو ألياف سلكية لتنظيف الجهاز، لأنها قد تخدش الأسطح.
- لمكونات صالحة للتنظيف في غسالة الأطباق.
- يمكن تركيب حجاب الضغط الخاص بالضغط بسهولة للتنظيف.

ضمان

- هذا الجهاز مضمون لمدة عامين . لمعرفة أحكام الضمان يرجى قراءة كرت ضمان المنتج.
- المكونات أداء غير مشمولة بالضمان:
 - المقابض.
 - أجزاء البدن القابلة للكسر.

العمر الافتراضي للجهاز يعتمد على ظروف التشغيل العادية . العمر الافتراضي 3 سنوات تقريبا.
يرجى الاتصال على أرقام خدمة الصيانة والتصليح الآتية:

الشركة المنفحة للإلكترونيات
المملكة العربية السعودية (الهاتف المجاني) 800 124 0900

البيئة



ويجب العرض الثالث والتمتع، يجب ألا يتم وضع هذا الجهاز في سلة النفايات المنزلية في نهاية عمره الافتراضي، ولكن يجب نقله إلى نقطة المركزية لإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. إن كلاً من الرمز الموجود على الجهاز، ودليل التعليمات والتعليق بجدارك من هذه السلسلة العامة، يمكن إعادة تدوير المواد المستخدمة في هذا الجهاز. من خلال إعادة تدوير الأجهزة المنزلية، فإنك تقدم إسهام هام للحفاظ على البيئة التي نعيش فيها. استفسر من السلطات المحلية عن نقطة التجميع.

الدعم

يمكنك الحصول على جميع المعلومات وقطع الغيار المتوفرة عبر الموقع الإلكتروني www.princesshome.eu