



EN Instruction manual

AR الاستخدام



Electric heater (Quartz)

Made in China
صنع في الصين

01.345011.09.001

PARTS DESCRIPTION / وصف الأجزاء



[WEEE Logo]



Made in China
صنع في الصين

© Princess 2017

EN Instruction manual

SAFETY

- By ignoring the safety instructions the manufacturer can not be hold responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.

- WARNING:** In order to avoid overheating, do not cover the heater.
- CAUTION:** Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- Children of less than 3 years should be kept away unless continuously supervised.
- Do not use the appliance with a programmer, timer, separate remote-control system or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
- Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
- Joists, beams and rafters shall not be cut or notched to install the appliance.
- Please do not install the appliance close to curtains and other combustible materials. This could cause a fire.
- The appliance shall, under no circumstances, be covered with insulating material or similar material.
- The fireguard does not give full protection for young children and for infirm persons.
- The fireguard of this heater is intended to prevent direct access to heating elements and must be in place when the heater is in use.
- The heater must not be located immediately below a socket-outlet.
- The heater needs to be installed so that the switches and other controls cannot be touched by a person in the bath or shower.
- WARNING:** The heater must not be used if the glass panels are damaged.
- WARNING:** This heater is not equipped with a device to control the room temperature. Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

PARTS DESCRIPTION

- Heating elements
- On / off switch
- Handle

BEFORE THE FIRST USE

- Place the device on a flat stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
 - Put the two back legs, separately supplied with the device, firmly in the recesses behind the appliance.
 - Put the power cable into the socket. (Note: Make sure the voltage which is indicated on the device matches the local voltage before connecting the device. Voltage 220V-240V 50/60Hz)
 - When the device is turned on for the first time, a slight odour will occur. This is normal, ensure adequate ventilation. This fragrance is only temporary and will disappear soon.
- Warning! Do not move the heater if the bulbs are still warm, this could damage the device.**

USE

- Plug into a grounded outlet and switch the device on by the on / off switches.
- The right on / off switch is for the upper element. The left on / off switch for the lower heating element. If one heater element is turned on, the unit has 400 watts of heating power, when both heaters are turned on, the unit has 800 watts of heating power
- Do not put anything on the heater, such as clothing or towels. Do not use the heater in the bathroom or other wet areas. The grates of the heater can be very hot.
- The exterior of the unit is hot. Avoid any physical contact, it can cause serious injury. Let it cool down completely before it is moved. Always use the handle on the top of the unit to move it.

CLEANING AND MAINTENANCE

- The appliance needs only an external regular cleaning.
- Before cleaning, unplug the appliance and wait for the appliance to cool down.
- Clean the grilles from dust.
- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.

WARRANTY

- This product is warrantied for 2 Years, for detailed terms, please refer to the Warranty Card.
- Following parts are not covered by warranty:
 - Knobs.
 - Any broken body parts.

Approximate life of this appliance under normal conditions is 3 Years.

For service and repairs, please call the following numbers:

United Electronics Co.
Saudi Arabia (Toll-free) 800 124 0900

ENVIRONMENT

- This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

AR دليل الإرشادات

- السلامة
- عند إهمال تعليمات السلامة لا تتحمل الشركة المصنعة أية مسؤولية عن وقوع تلفيات.
- في حالة تلف سلك الإمداد بالطاقة، يجب استبداله بواسطة الشركة المصنعة أو وكيل الصيانة أو أي في موهل لتجنب التعرض إلى المخاطر.
- لا تحرك الجهاز مطلقًا عن طريق سحب السلك، وتأكد من أن السلك لن يصبح متشابكًا.
- يجب وضع الجهاز على سطح ثابت ومستو.
- يجب ألا يغفل المستخدم عن الجهاز أثناء توصيله بالكهرباء
- تم تصميم هذا الجهاز للاستخدام المنزلي فقط وللأغراض التي صُنع من أجلها.
- ينبغي عدم استخدام هذا الجهاز بواسطة أطفال أصغر من 8 سنوات. يمكن استخدام هذا الجهاز بواسطة الأطفال من سن 8 سنوات وما فوق والأشخاص ذوي القدرات الجسدية أو الحسية أو العقلية المحدودة أو الذين يفتقرون إلى الخبرة والمعرفة إذا تم الإشراف عليهم أو إرشادهم بشأن كيفية استخدام الجهاز بطريقة آمنة وفهمهم للمخاطر المحتملة. يجب على الأطفال عدم اللعب بهذا الجهاز. احرص على بقاء الجهاز والسلك بعيدين عن متناول الأطفال أقل من 8 سنوات. يجب على الأطفال عدم القيام بعملية التنظيف وصيانة المستخدم إلا إذا كانوا أكبر من 8 سنوات وفي وجود من يشرف عليهم.
- حماية نفسك من التعرض إلى صدمة كهربائية، لا تغمس السلك أو القابس أو الجهاز في الماء أو في أية سوائل أخرى.
- تحذير: لتجنب فرط التسخين، لا تغطي المدفأة.
- تنبيه: قد تصبح بعض الأجزاء الخاصة بهذا المنتج ساخنة للغاية وقد تسبب حروق.
- يجب الانتباه جيدًا عند وجود أطفال أو ذوي احتياجات خاصة.
- يجب إقصاء الأطفال أقل من 3 سنوات إلا في حالة وجود من يشرف عليهم باستمرار.
- لا تستخدم الجهاز مطلقًا مع مبرمج أو مؤقت أو نظام منفصل للتحكم عن بعد أو أي جهاز آخر يقوم بتشغيل المدفأة أوتوماتيكياً؛ نظراً لوجود احتمالية التعرض لخطر نشوب حريق في حالة تغطية المدفأة أو وضعها بشكل غير صحيح.
- لا تستخدم المدفأة في المحيط المباشر للحمام أو منطقة الاستحمام أو حمام السباحة.
- يجب ألا يتم إزالة أو فتح الدعامات والحوامل والعارضات لتثبيت الجهاز.
- برجاء عدم تثبيت الجهاز بالقرب من الستائر أو من مواد أخرى قابلة للاحتراق. قد يتسبب هذا في نشوب حريق.
- يجب ألا يتم تغطية الجهاز تحت أي ظرف بمادة عازلة أو مادة مشابة.
- لا يسمح حاجر النار بحماية كاملة للأطفال الصغار والعاجزين.
- يخصص حاجر النار الخاص بهذه المدفأة لمنع الدخول المباشر لعناصر التسخين ويجب وضعه في مكانه عندما تكون المدفأة قيد الاستخدام.
- يجب ألا توضع المدفأة مباشرة تحت مقبس مخرج الطاقة.
- تحتاج المدفأة إلى تركيبها بحيث لا يمكن لأي شخص في الحمام أو أثناء الاستحمام لمس المفاتيح أو وحدات التحكم.
- تحذير: يجب ألا تستخدم المدفأة إذا كانت الألواح الزجاجية تالفة.
- تحذير: لم يتم تجهيز المدفأة بجهاز للتحكم في درجة حرارة الغرفة. لا تستخدم المدفأة في غرف صغيرة عندما يتواجد بها أشخاص غير قادرين على مغادرة الغرفة بأنفسهم ما لم يوجد من يشرف عليهم.

وصف الأجزاء

- عناصر التسخين.
- مفتاح التشغيل/إيقاف التشغيل
- مقبض

قبل الاستخدام الأول

- ضع الجهاز على سطح ثابت مستو وتأكد من وجود حد أدنى من المساحة الحرة حول الجهاز. قدرها 10 سم. هذا الجهاز غير مناسب للتركيب في خزانة أو للاستخدام الخارجي.
 - ضع الزحازتين الخلفيتين المرفقة على جنبتي مع الجهاز، بقوة في التجويف الخلفي في الجهاز.
 - ضع كابل الطاقة في المقبس (ملاحظة: تأكد أن جهد الكهرباء المشار إليه على الجهاز مطابق للجهد المحلي قبل توصيل الجهاز. الجهد الكهربائي 220-240 فولت. 50/60 هرتز)
 - عند تشغيل الجهاز للمرة الأولى، ستصدر رائحة خفيفة. هذا أمر طبيعي؛ تأكد من وجود قوة كافية. هذه الرائحة ما هي إلا رائحة مؤقتة وستختفي سريعًا.
- تحذير! تجنب تحريك السخان إذا كانت المصاب مازالت ساخنة لأن هذا قد يُلحق الجهاز.

الاستخدام

- وصل السلك بمخرج كهرباء موزع ثم قم بتشغيل الجهاز من خلال مفتاح on / off (تشغيل / إيقاف تشغيل).
- يخصص الجزء الأيمن من مفتاح on / off (تشغيل / إيقاف تشغيل) للآلة العلوية. بينما الجزء الأيسر من on / off (تشغيل / إيقاف تشغيل) يخص الآلة السفلية للتسخين. إذا كان السخان قيد التشغيل، فإن الوحدة بما 400 وات من طاقة التسخين، وعندما يكون كل من السخانين قيد التشغيل، فإن الوحدة بما 800 وات من طاقة التسخين
- يجب وضع أي شيء على السخان مثل الملابس أو المنادف. تجنب استخدام السخان في الحمام أو في أي منطقة مبللة. قد تصبح أجزاء السخان ساخنة للغاية.
- الجزء الخارجي من الوحدة ساخنة للغاية. تجنب أي ملامسة للجسم، لأن من الممكن التعرض لإصابات خطيرة. اتركه بهذا قائلاً قبل تحريكه. استخدم دائمًا المقبض أعلى الوحدة لتحريكه.

التنظيف والصيانة

- يجتاج الجهاز فقط لتنظيف منتظم من الخارج.
- قبل التنظيف افصل الجهاز من تلمس وانظر حتى يبرد الجهاز.
- نظف الشكات من الغبار.
- نظف الجهاز بقطعة قماش رطبة. لا تستخدم مطلقًا مواد تنظيف قوية أو كاشطة، أو اللف الحشن أو الألياف السلكية التي قد تسبب في تلف الجهاز.

صيانة

- هذا الجهاز مضمون لمدة عامين. لمعرفة أحكام الضمان يرجى قراءة كرت ضمان المنتج.
- المكونات أداة غير مشمولة بالضمان:

المقابض.

أجزاء البدن القابلة للكسر.

العمر الافتراضي للجهاز يعتمد على ظروف التشغيل العادية. العمر الافتراضي 3 سنوات تقريبا. يرجى الاتصال على أرقام خدمة الصيانة والتصلح الآتية:

الشركة المتحدة للإلكترونيات

المملكة العربية السعودية (خطأب مجاني) 800 124 0900

البيئة



وسبب العرض الثابت والصديق، يجب ألا يتم وضع هذا الجهاز في سلة القمامات المنزلية في غاية عمره الافتراضي، ولكن يجب نقله إلى النقطة المركزية لإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. إن كلاً من الرمز الموجود على الجهاز، ودليل التعليمات، والصديق بجوارك من هذه السلسلة العامة. يمكن إعادة تدوير المواد المستخدمة في هذا الجهاز. من خلال إعادة تدوير الأجهزة المنزلية، فإنك تقدم إسهام هام للحفاظ على البيئة التي نعيش فيها. استفسر من السلطات المحلية عن نقطة التجميع.