PRINCESS®

Made in China
صنع في الصين

EN Instruction manual
NL Gebruiksaanwijzing
FR Mode d'emploi
DE Bedienungsanleitung
ES Manual de usuario
PT Manual de utilizador
PL Instrukcja obsługi
IT Manuale utente
SV Bruksanvisning
CS Návod na použití
AR دليل المستخدم

جهاز مساج للقدمين ديلوكس / جهاز تدليك القدمين.

Foot Spa DeLuxe / Foot Spa DeLuxe Pro

01.565780.04.001 / 01.565781.04.001

EN Instruction manual

SAFETY INSTRUCTIONS

- Do not wind the cord tightly around the bath.
- Do not use the foot bath in the bathroom or shower, or near a sink(s) filled with water.
- Operate the bath with dry hands.
- Only allow the bath to be used by persons who can read and understand these instructions.
- Do not use the bath if it is damaged or if the cord is damaged. In this case, return the bath for repairs. A damaged cord can only be replaced by our technical service department with the special tools.
- This foot bath is intended for household use only.
- Children should be supervised to ensure that they do not play with the appliance.
- The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.
- If water leaks from the appliance, the appliance should no longer be used.

SETTINGS

Setting 0 - Off
Setting 1 - Vibration
Setting 2 – Infrared & Keep warm function
Setting 3 – Vibration & Infrared & Keep warm function

BEFORE THE FIRST USE

- Take the appliance and accessories out the box. Remove the stickers, protective foil or plastic from the device.
- Before using your appliance for the first time, wipe off all removable parts with a damp cloth. Never use abrasive products.
- Place the device on a flat stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.

USE

- Use a jug, small bucket or something similar to fill the bath with warm or cold water, whichever you prefer. The bath heater is strong enough to maintain the temperature of warm water for a period of time, but not to warm up cold water. So if you want a warm foot bath, use warm water of the desired temperature.
- Place a chair in front of the bath, plug in the appliance and switch it to the desired setting.
- First sit and then place your feet in the bath. Do not stand in the bath!
- Make sure that the water does not splash over the edge of the bath or on the selector switch.

CLEANING AND MAINTENANCE

- After use, switch off the bath and remove the plug from the socket.
- Clean the bath with clean water and a mild detergent, then dry off. Do not use any abrasive detergents or sponges.

GUARANTEE

- This product is guaranteed for 24 months granted. Your warranty is valid if the product is used in accordance to the instructions and for the purpose for which it was created. In addition, the original purchase (invoice, sales slip or receipt) is to be submitted with the date of purchase, the name of the retailer and the item number of the product.
- For the detailed warranty conditions, please refer to our service website: service.princess.info

WARRANTY

1. This product is warrantied for 2 Years, for detailed terms, please refer to the Warranty Card.
2. Following parts are not covered by warranty:
– Knobs.
– Any broken body parts.

Approximate life of this appliance under normal conditions is 3 years.
For service and repairs, please call the following numbers:
United Electronics Co.
Saudi Arabia (Toll-free) 800 124 0900

GUIDELINES FOR PROTECTION OF THE ENVIRONMENT

This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

SUPPORT

You can find all available information and spare parts at service.princess.info!

AR دليل المستخدم

تعليمات السلامة

تجنّب ثني السلك بشدة حول المسار الخاص به.

لا تستخدم جهاز تدميم القدم في الحمام أو تحت الدش أو بالقرب من أي وعاء مملوء بالماء.

شغّل الجهاز بيدين جافتين.

لا يجب السماح باستخدام الجهاز إلا بواسطة أشخاص يمكنهم قراءة هذه التعليمات وفهمها.

لا تستخدم الجهاز إذا كان تالفًا أو في حالة تلف الكبل. في هذه الحالة، يجب إعادة الجهاز لإجراء عمليات الإصلاح اللازمة. لا يجب استبدال الكبل التالف إلا بواسطة قسم الصيانة التقنية التابع لنا باستخدام أدوات محدّدة.

هذا الجهاز للاستخدام المنزلي فقط.

يجب مراقبة الأطفال لضمان عدم عبثهم بالجهاز.

يمكن استخدام الجهاز من قبل أطفال تبلغ أعمارهم 8 سنوات فأكثر والأشخاص ذوي القدرات المادية والحسية والعقلية المنخفضة أو الأشخاص الذين يفتقدون إلى الخبرة والمعرفة إذا ما توفر لهم الإشراف أو التعليمات الخاصة باستخدام الجهاز بطريقة آمنة وفهم المخاطر المعنية. يجب عدم عبث الأطفال بالجهاز. لا يجوز أن يتم تنظيف و صيانة الجهاز من قبل الأطفال إلا إذا كانت أعمارهم تزيد عن 8 سنوات ويتوفر لهم الإشراف.

سطح الجهاز يكون ساخنًا. يجب أن يتوخى الأشخاص الذين لديهم حساسية من الحرارة الحذر عند استخدام الجهاز.

يجب عدم استخدام الجهاز في حالة تسرّب للماء.

الإعدادات

الإعداد 0 - إيقاف التشغيل
الإعداد 1 - اهتزاز
الإعداد 2 - وظيفة الأشعة تحت الحمراء و الاحتفاظ بالحرارة
الإعداد 3 - اهتزاز ووظيفة الأشعة تحت الحمراء والاحتفاظ بالحرارة

قبل الاستخدام لأول مرة

أخرج الجهاز وملحقاته من العلبة. أزل جميع الملصقات والرقاقات المعدنية أو البلاستيكية الواقية من على الجهاز.

امسح كافة المقطع القابلة للإزالة بقطعة قماش مبللة قبل استخدام الجهاز لأول مرة. لا تستعمل المنظفات الكاشطة

ضع الجهاز على سطح مستقر وتأكد من وجود مساحة فارغة بحد أدنى 10 سم حول الجهاز. هذا الجهاز من غير الملائم تركيبه في مطبخ أو للاستخدام الخارجي.

الاستخدام

استخدم أبريقًا أو دلوًا صغيرًا أو أي شيء مشابه لتعبئة الجهاز بالماء الدافئ أو البارد، أيهما تريد. سخّان الجهاز قادر بقوة بالقدر الكافي للحفاظ على درجة حرارة الماء الدافئ لمدة زمنية ولكنه لا يمكنه تسخين الماء البارد. لذا، استخدم ماءً دافئًا بدرجة الحرارة التي تريدها إذا كنت تريد ذلك.

ضع كرسيًا أمام الجهاز، وقم بتوصيله بالطاقة وتشغيله وفقًا للإعداد المرغوب فيه.

اجلس أولاً و ضع قدميك داخل الجهاز. لا تقف وقدميك داخل الجهاز!

تأكد من عدم تناثر الماء على حواف الجهاز أو المفتاح.

التنظيف والصيانة

قم بإيقاف تشغيل الجهاز وفصل المقبس من القابس بعد الانتهاء من الاستخدام.

نظّف الجهاز باستخدام ماء نظيف ومنظف ناعم ثم جفّفه. لا تستخدم أي منظفات كاشطة أو قطع إسفنجية.

الضمان

هذا المنتج مضمون لمدة 24 شهرًا. الضمان الخاص بك يكون ساريًا إذا تم استخدام المنتج وفقًا للتعليمات وللغرض الذي صُمم من أجله. بالإضافة إلى ذلك، يتم تقديم فاتورة أو قسيمة المبيعات أو إيصال الشراء الأصلي مع تاريخ الشراء، واسم تاجر التجزئة ورقم المنتج.

يُرجى الرجوع إلى موقع خدمتنا، للاطلاع على شروط الضمان بالتفصيل: service.princess.info

الضمان

1. هذا المنتج مضمون لمدة 2 سنوات، للشروط التفصيلية يرجى الرجوع إلى بطاقة الضمان.
2. لا تشمل الأجزاء التالية الضمان:
– المقابض.
– أي أجزاء تالفة للجسم.

العمر الافتراضي لهذا الجهاز في الظروف العادية هو 3 سنوات.
للصيانة والإصلاح، يرجى الاتصال بالأرقام التالية:
الإلكترونيات المتحدة المحدودة
الهاتف المجاني (السعودية) 800 124 0900

مبادئ توجيهية لحماية البيئة

يجب عدم طرح هذا الجهاز في النفايات المنزلية في نهاية فترة استخدامه، ولكن يجب أن يُقدم إلى نقطة مركزية لإعادة تدوير الأجهزة المنزلية الكهربائية والإلكترونية. هذا الرمز الموجود على الجهاز، ودليل التعليمات ومواد التغليف تجذب انتباهك إلى هذه المسألة الهامة. المواد المستخدمة في هذا الجهاز يمكن إعادة تدويرها. من خلال إعادة تدوير الأجهزة المنزلية المستخدمة، فإنك تقدم مساهمة هامة لحماية بيئتنا. اطلب من السلطات المحلية معلومات بشأن نقاط إعادة التجميع.

الدعم

يمكنك أن تجد جميع المعلومات وقطع الغيار متاحة على الموقع service.princess.info!

© Princess 2016