## **PRINCESS**

**EN** Instruction manual



## **IONIC DETANGLING HAIRBRUSH** with Handle 01.529431.16.001

PARTS DESCRIPTION



## **EN** Instruction manual

- By ignoring the safety instructions the manufacturer cannot be held responsible for any damage.
- Do not block the negative ions emission port of this product.
- Do not insert any objects or your finger into the negative ion emission port. This may result in an accident.
- Do not expose this product to the sun for a long time, the ultraviolet rays may cause the brush to age and break easily.
- · Do not use the product on wigs.
- The user must not leave the product unattended while it is on.
- This product is only to be used for household purposes and only for the purpose it is made
- This product shall not be used by children aged less than 8 years. It can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the product in a safe way and understand the hazards involved. Children shall not play with the product. Keep the out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- Do not immerse the appliance in the water or any other liquid.
- After use, the appliance should be cleaned to avoid the accumulation of grease and other residues.
- WARNING: Do not use this product near bathtubs, showers, basins or other vessels containing water.

- The manufacturer cannot be held responsible for damages resulting from a failure to comply to the safety instructions.
- Do not expose the battery to high temperatures or direct sunlight. Never throw batteries into the fire. There is a danger of explosion!
- Keep batteries away from children. Batteries are not a toy!

• Do not open the batteries by force.

- Avoid contact with metallic objects.(Rings, nails, screws et cetera) there is a danger of short-circuiting!
- As a result of a short-circuit batteries may heat up consider-ably or even catch fire. this may result in burns.
- For your safety the battery poles should be covered with adhesive strips during transport.
- Do not touch a ruptured and/or leaking battery. If the liquid from the battery gets into your eyes, rinse your eyes as soon as possible with clean water, without rubbing your eyes. Immediately go to the hospital. If it is not treated properly, it can cause eye problems.

PARTS DESCRIPTION

- Power indicator lamp
- Release button Power switch
- Battery compartment
- Handlé Emission port Power off
- Power on 10. Vibrate/Ion on

**BEFORE THE FIRST USE** 

- Take the product out of the box. Remove the stickers, protective foil, or plastic from the product.
- Clean the product with a damp cloth before using it.

Installing or removing the brush pads

- To remove the brush pad press the brush pad release button. • To install the brush pad press it down onto the body of the brush. You will hear a click when it is correctly installed.
- Installing or removing the batteries
  The lonic Detangling Hairbrush uses 2 x 1.5V AA alkaline batteries. To install or remove the batteries -
- First remove the brush pad by pressing the brush pad release button.
  Install or remove the batteries.
- Always observe the polarity of the batteries when installing them.
- Using the lonic Detangling Hairbrush.

   Slide the power switch to the lons on position [lon]. The power indicator lamp will go on and the Ionic Detangling Hairbrush will
- continuously release negative ions.

   Alternatively, slide the power switch to the Vibrate/Ions. The power indicator lamp will go on and the Ionic Detangling Hairbrush will begin vibrating while it continuously releases negative ions. Using this helps this promote blood circulation to your scalp, helping to make your hair

**Note:** When the lonic Detangling Hairbrush is on, there will be soft "humming" sound coming from it. This is caused by the vibrations and the negative strontium ion generator and is quite normal. Please use the Ionic Detangling Hairbrush with confidence.

- Now gently brush your hair through for a smooth and shiny result.
- To fully experience the massage function, feel free to apply some pressure with the brush when using the vibrating feature.
   To turn off, slide the power switch to [O] off. The hissing sound may
- continue for a short time until all the negative ions are released.

  Remove the batteries from the lonic Detangling Hairbrush when it is not

CLEANING AND MAINTENANCE

- Use a soft, slightly damp cloth to clean the lonic Detangling Hairbrush.
   Do not allow water or any other liquid to get into the product.
   Use your fingers to remove any dust and hair from the brush pad.
- Remove the brush pad and wash it under a tap.
  Do not use corrosive liquids to clean the brush pad. This will cause
- damage to it. · Make sure the brush pad is completely dry before installing it.
- Storage
   Remove the batteries and store the lonic Detangling Hairbrush in a cool
- It is recommended to use and store this product at temperatures between 15°C to 35°C.

**ENVIRONMENT** X

This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

**Support**You can find all available information and spare parts at service.tristar.eu!





© Princess 2022 | Jules Verneweg 87 5015 BH Tilburg | The Netherlands | www.princesshome.eu